

# User Manual

Uninterruptible Power Supply

*LP33 Series 10 & 20*

10 & 20 kVA / 400Vac CE / S6

**GE Consumer & Industrial SA**

General Electric Company  
CH – 6595 Riazzino (Locarno)  
Switzerland

T +41 (0)91 / 850 51 51

F +41 (0)91 / 850 52 52

[www.gepowerquality.com](http://www.gepowerquality.com)



imagination at work



Certified  
Quality System  
**ISO 9001**

Model: **LP33 Series 10 & 20 CE S6**

Issued by: Product Document Department – Riazzino - CH

Approved by: R & D Department – Riazzino - CH

Date of issue: 01.07.2012

File name: GE\_UPS\_OPM\_LPS\_33E\_10K\_20K\_6GB\_V010

Revision: 1.0

Identification No.: 1025733

**Up-dating**

Revision

Concerns

Date

**COPYRIGHT © 2012 by GE Consumer & Industrial SA**

All rights reserved.

The information contained in this publication is intended solely for the purposes indicated.

The present publication and any other documentation supplied with the UPS system is not to be reproduced, either in part or in its entirety, without the prior written consent of *GE Digital Energy*.

The illustrations and plans describing the equipment are intended as general reference only and are not necessarily complete in every detail.

The content of this publication may be subject to modification without prior notice.

**Dear Customer,**

We thank you for selecting our products and are pleased to count you amongst our very valued customers at **GE Digital Energy**.

We trust that the use of the **LP33 Series 10 & 20** Uninterruptible Power Supply system, developed and produced to the highest standards of quality, will give you complete satisfaction.

Please read carefully the User Manual, which contains all the necessary information and describes all you need to know about the use of the UPS.

Thank you for choosing **GE Digital Energy** !

Distributed by:

Your service contact:



**GE Consumer & Industrial SA**  
General Electric Company  
CH – 6595 Riazzino (Locarno)  
Switzerland

# Table of contents

Page

<b>1</b>	<b>SAFETY RULES.....</b>	<b>6</b>
1.1	IMPORTANT SAFETY RULES.....	7
1.2	SAFETY SYMBOLS AND WARNINGS.....	10
<b>2</b>	<b>LAYOUT.....</b>	<b>11</b>
2.1	LAYOUT LP33 SERIES 10 & 20.....	11
<b>3</b>	<b>INTRODUCTION.....</b>	<b>12</b>
3.1	GENERAL DESCRIPTION.....	12
<b>4</b>	<b>DESCRIPTION.....</b>	<b>13</b>
4.1	PRINCIPAL DIAGRAM AND MAIN ELEMENTS DESCRIPTION .....	13
4.2	OPERATION MODES.....	14
4.3	RPA PARALLEL SYSTEM.....	17
4.4	SERVICE AND TECHNICAL SUPPORT .....	18
4.5	WARRANTY.....	18
4.6	RECYCLING AT THE END OF SERVICE LIFE .....	19
<b>5</b>	<b>INSTALLATION.....</b>	<b>20</b>
5.1	TRANSPORT .....	20
5.1.1	Dimensions and weights .....	21
5.2	DELIVERY.....	22
5.3	STORAGE.....	22
5.3.1	Storage of the UPS .....	22
5.3.2	Storage of the battery.....	22
5.4	PLACE OF INSTALLATION.....	23
5.5	VENTILATION AND COOLING .....	24
5.6	UNPACKING.....	25
5.7	ELECTRICAL WIRING.....	28
5.7.1	Fuse discrimination (co-ordination of breakers tripping).....	29
5.7.2	Fuse ratings.....	30
5.7.3	Input / output cable ratings .....	31
5.7.4	Installation requirements .....	32
5.8	ELECTRICAL CONNECTION.....	33
5.8.1	Power connection with common input mains.....	33
5.8.2	Power connection with separate input mains (option) .....	34
5.8.3	External battery connection.....	35
5.8.4	RPA system - Control bus connection .....	36
5.9	UPS FUNCTIONING AS FREQUENCY CONVERTER .....	38
<b>6</b>	<b>SYSTEM HANDLING.....</b>	<b>39</b>
6.1	CONTROL PANEL.....	39
6.2	TABLE OF FUNCTIONS AND INDICATIONS ON CONTROL PANEL .....	40
6.3	COMMAND SWITCHES AND FUSES .....	42
<b>7</b>	<b>LCD SCREEN.....</b>	<b>43</b>
7.1	HOME SCREEN.....	43
7.2	METERING.....	45
7.3	ALARMS.....	47
7.3.1	Events (alarms and messages) .....	48
7.3.2	Alarms list.....	48
7.3.3	Messages list.....	51
7.3.4	Event report LP33 Series 10 & 20.....	53
7.4	SETUP.....	54
7.5	COMMANDS.....	59

<b>8</b>	<b>OPERATION .....</b>	<b>60</b>
8.1	PROCEDURES FOR SINGLE LP33 SERIES 10 & 20 .....	60
8.1.1	Start-up of the LP33 Series 10 & 20 .....	60
8.1.2	UPS shut-down with load transfer on manual bypass Q2 .....	64
8.1.3	From Manual Bypass Q2 to normal function VFI .....	66
8.1.4	Complete UPS shut-down .....	67
8.1.5	Restore to normal operation after "Total Off" .....	68
8.1.6	Restore to normal operation after "EPO – Emergency Power Off" .....	69
8.2	PROCEDURES FOR LP33 SERIES 10 & 20 PARALLEL SYSTEM .....	70
8.2.1	LP33 Series 10 & 20 Parallel System start-up .....	70
8.2.2	Parallel UPS shut-down with load transfer on manual bypass Q2 .....	74
8.2.3	From Manual Bypass Q2 to normal function VFI .....	76
8.2.4	Separate a UPS unit from the Parallel System (System Redundancy) .....	77
8.2.5	Reconnect a UPS unit to a Parallel System .....	78
8.2.6	Complete Parallel System shut-down .....	79
8.2.7	Restore to normal operation after "Total Off" .....	80
8.2.8	Restore to normal operation after "EPO – Emergency Power Off" .....	81
<b>9</b>	<b>CUSTOMER INTERFACE .....</b>	<b>82</b>
9.1	SERIAL PORT J27 - RS232 .....	83
9.2	RELAY CARD .....	84
9.3	EPO (EMERGENCY POWER OFF) .....	85
<b>10</b>	<b>OPTIONS .....</b>	<b>86</b>
10.1	OPTIONS GENERAL VIEW .....	86
10.2	OPTIONS ASSEMBLY AND CONNECTION .....	87
10.2.1	Customer Interface board .....	87
10.2.2	Optional battery cabinet connection .....	90
<b>11</b>	<b>MAINTENANCE .....</b>	<b>91</b>
11.1	GENERAL MAINTENANCE .....	91
11.2	SERVICE REQUIRED .....	91
11.3	COOLING FAN MAINTENANCE .....	91
11.4	OTHER COMPONENTS WITH LIMITED LIFETIME .....	91
11.5	BATTERY MAINTENANCE .....	92
11.6	UPS ROOM CONDITIONS AND TEMPERATURE .....	92
<b>12</b>	<b>NOTES .....</b>	<b>93</b>
12.1	NOTES FORM .....	93
<b>13</b>	<b>ANNEX .....</b>	<b>94</b>
13.1	TECHNICAL DATA SHEET .....	94
13.2	UPS SCHEMATIC DIAGRAMS .....	94
13.3	CD-ROM .....	94

# 1 SAFETY RULES

With this document, **GE Digital Energy** gives to the user all the necessary information about the correct use of the UPS.

Please read carefully this **User Manual** before installing or operating the UPS.  
We recommend that this manual be kept next to the UPS for future references.

If any problems are encountered with the procedures contained in this manual, please contact the nearest **Service Centre** before you proceed.

All UPS installation, maintenance and service work should be performed by qualified service personnel only.

The **KNOWLEDGE** and the **FULLY** compliance of the safety instructions and the warning contained in this manual are

**THE ONLY CONDITION**

to avoid any dangerous situations during installation, operation, maintenance work, and to preserve the maximum reliability of the UPS system.



**NOTE !**

*LP33 Series 10 & 20* is a Category C2 UPS Product (Class A - according to IEC 62040).

In a domestic environment, this product may cause radio interference, in which case, the user may be required to take additional measures.



**ATTENTION !**

While every care has been taken to ensure the completeness and accuracy of this manual, **GE Digital Energy** assumes no responsibility or liability for any losses or damages resulting from the use of the information contained in this document.

**GE Digital Energy** refuses any responsibility in case of non-observance, unauthorised alterations or improper use of the delivered UPS.

## 1.1 IMPORTANT SAFETY RULES

### GENERAL

- Move the UPS in an upright position in its original package to the final destination room.
- To lift the cabinets, use a forklift or lifting belts with spreader bars.
- Check for sufficient floor and elevator loading capacity.
- Check carefully the integrity of the UPS equipment.  
In case you note some visible damage, do not put the UPS under voltage, but contact the nearest *Service Centre*.
- **WARNING: RISK OF ELECTRICAL SHOCK.**  
Apart the front hinged lockable doors, do not remove any covers, there are no user serviceable parts inside.
- After switching off takes min. 5 minutes for the DC capacitors to discharge because a lethally high voltage remains at the terminals of the electrolytic capacitors.
- All maintenance and service work should be performed by qualified service personnel.
- The outlet-bars may be electrically live, even when the UPS is disconnected from the mains.
- Dangerous voltages may be present during battery operation.
- The battery protections must be removed before any maintenance or service work.
- Be aware that the inverter can restart automatically after the utility voltage is restored.
- End user must follow applicable regional occupational safety codes/regulations during installation, operation and equipment maintenance.  
This may require additional field marking or labelling defining appropriate level of PPE (Personal Protection Equipment) to reduce the risk of Arc-flash related injuries.  
Contact our Technical Support for product specific information.

### INSTALLATION

- This UPS must be installed and connected only by trained personnel.
- Verify accurately during Commissioning and Maintenance of the UPS, for the following:  
Damaged components, squeezed wires and cables, or not correctly inserted plugs.
- After removing the sidewalls of the UPS, make sure that all earth connections when reassembling, are correctly reattached.
- This UPS is intended for use in a controlled indoor environment free of conductive contaminants and protected against animals intrusion.
- High earth leakage current: Earth connection essential before connecting to AC input.
- Switching OFF the unit does not isolate the UPS from the mains.
- Do not install the UPS in an excessively humid environment or near water.
- Avoid spilling liquids on or dropping any foreign object into the UPS.
- The unit must be placed in a sufficiently ventilated area; the ambient temperature should not exceed 40°C (104°F).
- Optimal battery life is obtained if the ambient temperature does not exceed 25°C (77°F).
- It is important that air can move freely around and through the unit.
- Do not block the air vents.
- Avoid locations in direct sunlight or near heat sources.

## STORAGE

- Store the UPS in a dry location; storage temperature must be within -25°C (-13°F) to +55°C (131°F).
- The optimal temperature for Battery storage is 20°C (68°F) to 25°C (77°F) and shall never exceed the range -20°C (-4°F) to 40°C (104°F).
- If the unit is stored for a period exceeding 3 months, the batteries must be recharged periodically (time depending on storage temperature).

## BATTERY

- The battery-voltage is dangerous for person's safety.
- When replacing the battery, use the same number, voltage (V) and capacity (Ah). Do not connect battery strings of different type in parallel.
- Proper disposal or recycling of the battery is required. Refer to your local codes for disposal requirements.
- Never dispose of battery in a fire: they may explode.
- Do not open or mutilate battery: their contents (electrolyte) may be extremely toxic. If exposed to electrolyte, wash immediately with plenty of water.
- Avoid charging in a sealed container.
- Never short-circuit the batteries.
- When working with batteries, remove watches, rings or other metal objects, and only use insulated tools.



### **WARNING !**

**The UPS contains hazardous voltages.**

**Observe carefully the safety instructions to prevent risk of electrical shock.**

# RPA

Redundant Parallel  
Architecture

## ***Parallel version secured with RPA***

***When included in the text, this symbol refers to operation needed only for Parallel System.***

## Safety instructions when working with battery



**EXTERNAL BATTERY MUST BE INSTALLED AND CONNECTED TO THE UPS BY QUALIFIED SERVICE PERSONNEL.**  
**INSTALLATION PERSONNEL MUST READ THIS ENTIRE SECTION BEFORE HANDLING THE UPS AND BATTERY.**

### **DANGER!**

Full voltage and current are always present at the battery terminals.

The battery used in this system can provide dangerous voltages, extremely high currents and a risk of electric shock.

If the terminals are shorted together or to ground they may cause severe injury.

You must be extremely careful to avoid electric shock and burns caused by contacting battery terminals or shorting terminals during battery installation.

Do not touch uninsulated battery terminals.

A qualified service person, who is familiar with battery systems and required precautions, must install and service the battery.

The installation must conform to national and local codes.

Keep unauthorised personnel away from the battery.

The qualified service person must take these precautions:

- 1 Wear protective clothing, such as rubber gloves and boots and protective eye wear  
 Batteries contain caustic acids and toxic materials and can rupture or leak if mistreated.  
 Remove rings and metal wristwatches or other metal objects and jewellery.  
 Do not carry metal objects in your pockets where the objects can fall into the battery cabinet.
- 2 Tools must have insulated handles and must be insulated so that they will not short battery terminals.  
 Do not allow a tool to short between individual or separate battery terminals or to the cabinet or rack.  
 Do not lay tools or metal parts on top of the battery, and do not lay them where they could fall onto the battery or into the cabinet.
- 3 Install the battery as shown on the drawing provided with the battery.  
 When connecting cables, never allow a cable to short across a battery's terminals, the string of battery, or to the cabinet or rack.
- 4 Align the cables on the battery terminals so that the cable lug will not contact any part of the cabinet or rack, even if the battery is moved.  
 Keep the cable away from any sharp metal edges.
- 5 Install the battery cables in such a way that the UPS or battery cabinet doors cannot pinch them.
- 6 Do not connect the battery terminal to Ground.  
 If any battery terminal is inadvertently grounded, remove the source of the ground.  
 Contacting any part of a grounded battery can cause a risk of electric shock.
- 7 To reduce the risk of fire or electric shock, install the battery in a temperature and humidity controlled indoor area, free of contaminants.
- 8 Battery system chassis ground (earth) must be connected to the UPS chassis ground (earth).  
 If you use conduits, this ground conductor must be routed in the same conduit as the battery conductors.
- 9 Where conductors may be exposed to physical damage, protect the conductors in accordance with all applicable codes.
- 10 If you are replacing the battery or repairing battery connections, shut OFF the UPS and remove the battery fuses.



## 1.2 SAFETY SYMBOLS AND WARNINGS

### Safety warnings

The text of this manual contains some warnings to avoid risk to the persons and to avoid damages to the UPS system and the supplied critical loads.

The non-observance of the warnings reminding hazardous situations could result in human injury and equipment damages.








Please pay attention to the meaning of the following warnings and symbols:

	<b>WARNING !</b> Referred to procedures or operations which could cause damages to the persons or to the system, when not correctly operated.
	<b>NOTE !</b> Warns the user about important operations or procedures described in this manual.

### Safety symbols

When the text includes one or more of the following symbols, that means exist a potentially hazardous situations.

Please remind the meaning of each symbol.

	<b>CAUTION</b> Related to all the potentially hazardous situations which may result in injury.
	<b>DANGER OF PARTS ELECTRICALLY LIVE</b> Related to all the situation with potentially hazardous voltage.
	<b>DANGER OF EXPLOSION</b> Used to indicate conditions where exploding parts can cause serious injury.
	<b>DANGER OF CRUSHING</b> Used when moving the equipment due to the heavy weight.
	<b>DANGER OF OVERHUNG LOAD</b> Used when the equipment is lifted by a crane.
	<b>DANGER OF HOT SURFACE</b> Used to indicate conditions of elevated temperature on some parts.
	<b>DO NOT TOUCH</b> Risk of parts with hazardous voltages or parts in movement.

## 2 LAYOUT

### 2.1 LAYOUT LP33 SERIES 10 & 20




Fig. 2.1-1 General view




Fig. 2.1-2 Front view




Fig. 2.1-3 Side view



Fig. 2.1-4 Control panel




Fig. 2.1-5 General view without protection panels

1	Input Mains and Output Load
CI	Costumer Interface Board (option)
F1-F2-F3	Rectifier input fuses
F9-F10-F11	Battery fuses
Q1	UPS Output switch
Q2	Manual Bypass switch
RC	Relay card
RPA	RPA board (option)
RS232	Serial Port RS232
SNMP	3-ph SNMP/WEB plug-in adapter (option)

## 3 INTRODUCTION

### 3.1 GENERAL DESCRIPTION

The **LP33 Series 10 & 20 Uninterruptible Power Supply** (UPS) provides the energy supply for critical loads which need a reliable, continuous free from voltage disturbances and frequency fluctuations supply.

In case the *mains fails*, or it exceeds the permitted tolerances, the energy to supply the *load* is furnished by the **battery** with a backup time dependent on its capacity, until the mains recovers.



**LP33 Series 10 & 20** is a truly **VFI** double conversion **Uninterruptible Power Supply** (UPS), equipped with *automatic bypass*, where the **load** is normally supplied by the **inverter**.



Eco Mode


**LP33 Series 10 & 20** can be configured, if chosen, for the **ECO Mode** permitting the maximum energy saving.

The main typical performances of the **LP33 Series 10 & 20** system are the following:

- **VFI (Voltage Frequency Independent) double conversion technology to provide an excellent quality power supply.**
- **Input power factor 1.**
- **Input current THD <8%.**
- **Automatic bypass and manual bypass to improve reliability and maintenance.**
- **Microprocessor controlled supervision.**
- **Dual AC inputs (Option).**
- **ECO Mode operation.**
- **Compact and agreeable design expressly conceived for "Office environment".**
- **Low level acoustic sound, to avoid noise to the persons operating in the same environment.**
- **Multi-language LCD screen.**
- **Total battery management: SBM (Superior Battery Management)**
- **High battery capacity, 25 minutes (10 kVA) and 10 minutes (20 kVA), with battery mounted inside the UPS cabinet.**
- **Wide rectifier input voltage tolerance: 323 ÷ 460Vac (phase - phase).**
- **Wide rectifier input frequency tolerance: +/-10% (45 ÷ 55 for 50Hz and 54 ÷ 66 for 60Hz).**
- **RPA (Redundant Parallel Architecture) up to 4 units.**
- **GE Connectivity.**
- **Compliance with European standard IEC 62040.**

## 4 DESCRIPTION

### 4.1 PRINCIPAL DIAGRAM AND MAIN ELEMENTS DESCRIPTION



The Uninterruptible Power Supply System **LP33 Series 10 & 20** can be divided into the following main elements:

#### Electronics

The UPS is designed with a microprocessor-controlled supervision and diagnostic system. Communication between user and UPS is achieved by the *Control Panel* consisting of an *LCD screen*, displaying the operation modes, the measurements and the events / alarms.

#### Rectifier

The *rectifier* converts the 3-phase mains voltage into a controlled and regulated DC-voltage, supplying the *inverter* and to charge the *battery* through the *battery-charger*.

#### Inverter

The *inverter* converts the DC voltage into a three-phase sinusoidal with constant amplitude and frequency, which is completely independent from the AC-input voltage.

#### Automatic Bypass

The *automatic bypass* consists of a static semiconductor-switch (SSR: Static Switch Relay), used to provide an uninterrupted transfer of the *load* from *inverter* to *mains* when operating in *VFI (Voltage Frequency Independent) Mode*.

If chosen the *ECO Mode*, the SSM transfer the *load* from *mains* to *inverter* in case the utility fails.

#### Back-Feed Protection

All **LP33 Series 10 & 20** UPS's are equipped with an automatic system for the protection against voltage back feeding towards Utility, through the Bypass (Applied Standard IEC 62040-1).

This protection works automatically by opening *contactor K6* (in series with the thyristors of the static switch) and eventually *K7*, and acts in case of internal defects of the system, or due to wrong manipulations on the *maintenance bypass Q2*.

#### Manual Bypass

The *manual bypass* consists of a pair of manual switches *Q1* and *Q2*, which allow the isolation of the UPS from the *load*, while still supplying the *load* with power directly from the *mains*.

#### Battery

The *battery*, normally stored by the *battery-charger*, supplies the DC energy to *inverter* in the event of *mains* failure.

## 4.2 OPERATION MODES

This section describes the different possible operation modes of the UPS explaining the function of the main modules of the UPS.

### VFI (Voltage Frequency Independent) mode operation

Under normal conditions the **load** is permanently powered by the **inverter** with constant amplitude and frequency.

The **rectifier**, powered by the **mains**, supplies the **inverter** and the **battery-charger** keeps the **battery** fully charged.




Fig. 4.2-1 Energy flow in VFI Mode operation

The **inverter** converts the DC voltage in a new AC sine wave voltage with constant amplitude and frequency independently from the input **mains** power.

### ECO Mode operation

When the **ECO Mode** is selected, and the **mains** power is available, the **load** is normally powered through the **automatic bypass**.

When the mains voltage is detected out of the prescribed tolerances, the **load** is automatically transferred to the **inverter**.

When the **mains** recovers, the **load** returns to the **automatic bypass** after a variable time defined by the control unit.




Fig. 4.2-2 Energy flow in ECO Mode operation

The **ECO Mode** can be configured directly by the user for higher efficiency, considering the **mains** reliability and criticality of the **load**.

The selection between the two operation modes "**VFI Mode** and **ECO Mode**", or switching between operation modes at required time, can be done through the UPS **control panel** (see Section 7.4 / ECO Mode).

# RPA

Redundant Parallel Architecture


## In case of Parallel System

ECO Mode cannot be enabled for RPA Parallel System.

Attention: A single unit equipped with a RPA - Parallel board, must be considered as parallel, thus disabling ECO Mode.

## Automatic bypass operation

In **VFI** (Voltage Frequency Independent) operation mode, the **load** is permanently supplied by the **inverter** but, in case of trouble on the **inverter**, or when overload or short-circuit on the output occur, if the **mains** voltage do not exceed the admitted tolerances, the **load** is instantly transferred to the **mains** through the **automatic bypass**, taking advantage of the higher short circuit power.



When the **inverter** recovers, the **load** will be re-transferred automatically to the **inverter**.

## RPA

Redundant Parallel Architecture

### In case of Parallel System

*Each unit has its own bypass.*

All the bypasses in the system work together, their control being managed in the same manner by all units.

*The units are continuously exchanging information before taking such decision.*


*In case the inverter of one unit fails, its bypass remains operating.*

*It is excluded only if the unit is separated from the common bus by opening its output switch Q1.*

## Mains recovery operation

As soon as the **mains** recovers, the **rectifier** starts up automatically supplying the **inverter** and the **battery-charger** recharges the **battery**.

In case the **inverter** has been shut down following a complete discharge of the **battery**, when the **mains** recovers the system start-up automatically.



When the energy stored in the **battery** is sufficient to ensure a minimum time of operation with the actual load, in case of a future **mains** failure, the **load** will be retransferred to **inverter** (if selected VFI Mode).

## RPA

Redundant Parallel Architecture

### In case of Parallel System

*When the AC input power recovers, the rectifiers will start-up sequentially according to their number in the Parallel System in order to avoid an initial inrush current.*


*The inverters will start-up automatically, but only when the battery has recharged enough for a minimum runtime with the present load.*

*When enough inverters to supply the load have been restarted, the load will be transferred from the automatic bypass back to the inverter bus-bars.*

## Manual bypass operation

The **manual bypass** circuit consisting of **Q1** and **Q2** manual switches, permits the transfer of the **load** directly to the **mains** without interruption, leaving the UPS galvanically separated from the output **load**.


This type of operation is normally used when the UPS system must be completely turned off for maintenance or repair.



## Mains failure operation

In the event of a **mains** power failure, the **rectifier** and the **battery-charger** turns OFF, while the **inverter** continues to supply the **load** without interruption using the energy stored in the **battery**.

During the **battery** discharge, the **LCD** screen displays the remaining autonomy, based on the **battery** capacity and the applied **load**.



In the event of an extended mains failure, before the **battery** is fully discharged, the alarm “**stop operation**” warns the user that the UPS will start the shut-down procedures when the indicated time expired (normally 3 minutes).

## RPA

Redundant Parallel  
Architecture

### In case of Parallel System

#### With Parallel System for power capacity:

- With the **bypass mains power available** as the warning “battery low” occurs on one unit, after timeout (selectable) the load is transferred to mains.
- With **missing bypass mains power** as the warning occurs on one unit, the system starts the timeout (selectable) of “Stop operation” and then the output load shuts down.

#### With redundant Parallel System:

- As the warning battery low occurs on one unit unnecessary to support the present load, after timeout (selectable) this unit shuts down and the load is shared between the other units. As the warning occurs on one unit necessary to support the present load, the system starts the timeout (selectable) of “stop operation” and then the output load shuts down.



### 4.3 RPA PARALLEL SYSTEM

The *RPA (Redundant Parallel Architecture)* allows to extend the unit to a Parallel System with 2, 3, or 4 units *LP33 Series 10 & 20* connected on the same bus, which ensure the highest reliability rate and increase the power availability.

#### Parallel system for power capacity


Two or more units can be paralleled in order to achieve output power superior to the maximum power delivered by a single UPS unit.

The maximum total load shared between the  $n$  parallel units can achieve the 100% of the installed nominal power system.

In the event of one unit fails, the load will be suddenly transferred to the mains by the bypass.

#### Parallel system for redundancy

The *Parallel System* can be defined redundant only in case the nominal power rating of  $n-1$  units of  $n$  parallel units is sufficient to supply the required load power.



The load in a *Parallel Redundant System*, is equally shared by  $n$  units connected on the output bars. Should one of the parallel units trip off-line, the remaining ( $n-1$ ) units will share the load maintaining the applications protected by inverter until the normal situation restores.

#### Load sharing between parallel units

The control bus exchanging the data between the microprocessors of the paralleled units provide for a constant proportional load sharing in every load condition.

#### Management and synchronisation of the Parallel System

All the units are identical without master and slaves.

One unit is arbitrarily selected as the reference (the first unit connected on power bus) being this unit the first synchronised with the mains voltage, and all the other units synchronise with the first one.

In case the reference unit fails or it is excluded from the parallel power bus any other unit will take over the reference role.

The AC input power source of all the bypasses must be the same for all the units of the Parallel System excluding any phase shift between them.

#### Control bus of the Parallel System

A high-speed serial bus, guarantees communication, synchronization and load sharing between the UPS modules.

Each module controls its own function, while the Master (each unit can be Master) controls and commands the status of the system.



#### NOTE !

No transformers, fuses or automatic circuit breakers should be inserted between the unit's output and the load common bus-bars.

## 4.4 SERVICE AND TECHNICAL SUPPORT

For any request of technical support please contact your local *Service Centre*.

Stamp of your local Service Centre (see page 3)





Fig. 4.4-1 Identification label

The requested data permitting to identify your UPS are marked on the *identification label* fixed on the front of the cabinet, behind the lower front door.

For fast and efficient Technical Support solutions, please mention the data marked on the identification label.

## 4.5 WARRANTY

GE Digital Energy, operating through its authorised agents, warrants that the standard products will be free of defects in materials and workmanship for a period as per contract specifications.



### NOTE !

This warranty does not cover failures of the product which result from incorrect installation, misuse, alterations by persons other than authorised agents, or abnormal working conditions.

## 4.6 RECYCLING AT THE END OF SERVICE LIFE



### NOTE !

This product has been designed to respect the environment, using materials and components respecting eco-design rules.

It does not contain CFCs (Carbon Fluor Clorid) or HCFCs (Halogen Carbon Fluor Clorid).



### RECYCLING AT THE END OF SERVICE LIFE !

*GE Digital Energy*, in compliance with environment protection recommends to the *User* that the UPS equipment, at the end of its service life, must be recovered conforming to the local applicable regulations.



### BATTERY DISPOSAL

This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union.

See the product documentation for specific battery information.

The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg).

For proper recycling return the battery to your supplier or to a designated collection point.

For more information see: [www.weeerohsinfo.com](http://www.weeerohsinfo.com)

## 5 INSTALLATION

### 5.1 TRANSPORT

The UPS is fixed on transport socket suitable for forklift, which includes a special layer of *Ethafoam* to protect the equipment against the transport shock. Normally the UPS is packaged with carton box. On request the equipment can be packaged in wooden case.


The UPS must be moved in **upright position**.

Do not tilt cabinets **more than  $\pm 10^\circ$**  during handling.

Move the UPS in its **original package** to the final destination room.

**Do not stack other package on top:** they could damage the upper side of the cabinet.

	<p><b>NOTE !</b></p> <p>When moving the UPS, pay attention to:</p>				
--	--	--	--	--	--



#### Forklift

The UPS may be lifted with a forklift in upright position from right and left side.

Take note of the centre of gravity marked on the package.

<p><b>NOTE !</b></p> <p>Check for sufficient floor and elevator loading capacity.</p> <p>Transport UPS only in upright position.</p> <p>Do not stack other package on top of the UPS.</p>


#### Crane

If the UPS has to be lifted by crane, use suitable carrying belts taking note of the centre of gravity marked on the package.


**Take all necessary precautions to avoid damage to the cabinet while hoisting the UPS.**

	<p><b>WARNING !</b></p> <p>When loading / downloading and when moving the UPS, it is forbidden:</p> <p>When loading / downloading and when moving the UPS, pay attention to:</p>		

### 5.1.1 Dimensions and weights



<b>LP33 Series 10</b>	
UPS dimensions (W x D x H):	500 x 780 x 1320 mm 19.69 x 30.71 x 51.97 "
Weight UPS without battery:	140 kg / 309 lbs
Floor loading UPS without battery:	359 kg/m <sup>2</sup>
Weight UPS with battery 7Ah / 14Ah:	270 (7Ah) / 370 (14Ah) kg 596 (7Ah) / 816 (14Ah) lbs
Floor loading UPS with battery 7Ah / 14Ah:	693 (7Ah) / 949 (14Ah) kg/m <sup>2</sup>
Weight UPS without battery and standard shipping:	170 kg / 375 lbs
Weight UPS with battery 7Ah / 14Ah and standard shipping:	300 (7Ah) / 400 (14Ah) kg 662 (7Ah) / 882 (14Ah) lbs



<b>LP33 Series 20</b>	
UPS dimensions (W x D x H):	500 x 780 x 1320 mm 19.69 x 30.71 x 51.97 "
Weight UPS without battery:	150 kg / 331 lbs
Floor loading UPS without battery:	385 kg/m <sup>2</sup>
Weight UPS with battery 14Ah:	375 kg / 827 lbs
Floor loading UPS with battery 14Ah:	962 kg/m <sup>2</sup>
Weight UPS without battery and standard shipping:	180 kg / 397 lbs
Weight UPS with battery 14Ah and standard shipping:	405 kg / 894 lbs



#### NOTE !

The weight of each single piece is marked outside the package!

## 5.2 DELIVERY

When delivered, check carefully the **package integrity** and the **physical conditions of the UPS equipment**.

In case of any damage sustained during transport, immediately inform the carrier and contact your local **Service Centre**.

A **detailed report** of the damage is necessary for any insurance claim.




### NOTE !

A damaged UPS must never be installed or connected to mains or battery!

## 5.3 STORAGE

### 5.3.1 Storage of the UPS



The equipment is carefully packed for transport and storage so that it is in a perfect condition when eventually installed.

Never leave an UPS outside the building and do not store the UPS one on top of the other.

We recommend to store the UPS in its original package in a dry, dust-free room, away from chemical substances, and with a temperature range not exceeding **-25°C (-13°F)** to **55°C (131°F)**.

In case the battery is included please refer to *Section 5.3.2*.


Some important functions of the UPS, such as the customized functions, are defined by parameters stored in a **RAM memory**. A small backup *Battery* located on the Control Unit board supplies the RAM.

If the storage time of the UPS exceeds **1 year**, these functions **should be verified** by an authorized *Service Centre* before putting the UPS into operation.



### NOTE !

In case of storage of the UPS pay attention to:



FRAGILE



SENSITIVE TO DAMPNES



SENSITIVE TO HEAT



SENSITIVE TO FROST

### 5.3.2 Storage of the battery

When the delivery includes a maintenance free *Battery*, keep in mind that they are subject to self-discharge and therefore you must recharge the *Battery*.

The storage time without *Battery* recharge depends on the temperature of the storage site.

The optimal temperature for *Battery* storage is **20°C (68°F)** to **25°C (77°F)** and shall never exceed the range **-20°C (-4°F)** to **40°C (104°F)**.

In case of a *maintenance free battery*, the storage time without charging the *battery* is approximately:

6 months with storage temperature 20°C (68°F)


3 months with storage temperature 30°C (86°F)

2 months with storage temperature 35°C (95°F)



### NOTE !

In case of *battery* storage pay attention to:



FRAGILE



SENSITIVE TO DAMPNES



SENSITIVE TO HEAT



SENSITIVE TO FROST

## 5.4 PLACE OF INSTALLATION



### WARNING !

UPS installation and connection must be performed by **QUALIFIED SERVICE PERSONNEL** only.

The UPS should be installed in a **restricted area** where only qualified personnel should be admitted.

The place of installation **should be clean, dust-free**, and provided with proper **ventilation or air-conditioning**.

Verify for **sufficient floor load capacity** (see *Section 5.1.1*).

We strongly advice that the ambient temperature should not exceed **20° to 25°C / 68° to 77°F** (max. 40°C / 104°F). See *Section 5.5*.



### NOTE !

Insufficient space on both sides of the UPS in respect to the wall can cause a dangerous increase of the internal operating temperature.




Fig. 5.4-1 LP33 Series 10 & 20 positioning




Fig. 5.4-2 RPA Parallel System positioning

### LP33 Series 10 & 20 positioning

For easier access in case of maintenance operation and for a free circulation around the cabinet, we recommend to maintain the following minimum distances:

Right & left side:	<b>100 mm</b>	(4")
Rear side:	<b>50 mm</b>	(2")
Top of the UPS:	<b>300 mm</b>	(12")

### RPA

Redundant Parallel Architecture

Right & left side:	<b>200 mm</b>	(8")
Rear side:	<b>50 mm</b>	(2")
Top of the UPS:	<b>300 mm</b>	(12")



### NOTE !

**Both lateral sides of the UPS MUST BE ACCESSIBLE** at any time for repair or maintenance.



### NOTE !

Operating temperature is very important for *valve regulated battery* (maintenance free).


Operation at temperatures higher than 20°C (68°F) will reduce life expectancy.

Respect the prescription VDE 0510, those of the battery supplier and other local standards.

The installation and cabling of the battery must be done by qualified people.

## 5.5 VENTILATION AND COOLING

The heat produced by the UPS is transferred to the environment by its internal blowers.



### Airflow through the UPS

It is important that the cooling air can freely flow through the air inlets and outlets of the UPS.




#### NOTE !

Insufficient distances on both sides of the UPS could increase the temperature inside the UPS.

Do not put any object on the top of the cabinet: it might obstruct the air flow.

### Heat evacuation from UPS room

The heat must be evacuated from the environment with a proper cooling / ventilation system provided by the user.



### Air volume and losses of the UPS

The approximate minimum air volume needed to evacuate the heat generated by the UPS, for **inlet temperature max. 35°C (95°F)**, for the standard version at inverter nominal load with **PF = 0.8 lag.** and **battery charged**, are the following:

UPS model	Air volume		Losses	
	VFI Mode	ECO Mode	VFI Mode	ECO Mode
LP33 Series 10	235 m <sup>3</sup> /h	45 m <sup>3</sup> /h	0.78 kW	0.15 kW
LP33 Series 20	430 m <sup>3</sup> /h	70 m <sup>3</sup> /h	1.47 kW	0.23 kW

## 5.6 UNPACKING

Move the equipment in its original packing, carton box or wooden case, until the place of installation and remove the packing and the transport sockets only just before installing the UPS.




Fig. 5.6-1 LP33 Series 10 & 20 unpacking sequence

Procedure for the unpacking of the UPS:

- Make sure to have sufficient space around the UPS before you start unpacking.
- Cut the two straps "A" fixing the carton box.
- Remove the wooden top cover "B", which will be used as a ramp and position it as shown in the picture.
- Remove the protection "C" outside the cabinet and the accessories bag.
- Remove the carton box "D".
- Remove the 2 angle irons "E", which are fixing the UPS to the wooden base "G" by unscrewing bolts "F".
- Push now the UPS towards the ramp "B" and let it slide down the ramp.  
This has to done with the utmost care!



### NOTE !

Be aware of the heavy weight of the UPS, in particular if already equipped with Batteries.



White colour = without any anomaly  
Red colour = anomaly evidence




Fig. 5.6-2 ShockWatch device

The package of the LP33 Series 10 & 20 is equipped with *ShockWatch* (indicator for shock), and *TiltWatch* (indicator for overthrow) on the outside.

These devices indicate an eventual shock or overthrow during transport.



Fig. 5.6-3 TiltWatch device




Whenever these devices show a possible anomaly, the UPS shall not be commissioned before consulting a "Service Centre".

Included in the delivery you can find the following parts:

- An accessories bag.
- Control Bus cables (only for RPA system).
- 2 bolts to support the UPS cabinet (see Fig. 5.6-4).
- CD-ROM connectivity.

### Bolts to block and support the LP33 Series 10 & 20



Make use of the 2 bolts, as shown in the picture, in case you desire to block the UPS on it's position.

The bolts can be used either on the front or the rear of the UPS.

The height can be adjusted with the 2 enclosed nuts "A", taking care however, that the weight of the UPS remains on the wheels.

The UPS can also be screwed directly to the floor on each leg.

Fig. 5.6-4 Bolts to block the LP33 Series 10 & 20 on it's position



#### NOTA !

The wheels are designed only for limited movements on the installation site.



#### NOTE !

A damaged UPS must never be installed or connected to *mains* or *battery*!

In case of any damage sustained during the transport, immediately inform the shipping agent!

A detailed report of the damage is necessary for any indemnity claim.



#### PACKING MATERIAL RECYCLING

GE Digital Energy, in compliance with environment protection, use only environmentally friendly material.

UPS packing materials must be recycled in compliance with all applicable regulations.

## 5.7 ELECTRICAL WIRING



### WARNING !

The connections to and from the UPS must be executed by **QUALIFIED PERSONNEL ONLY**.

Refer to the "*Safety prescriptions - Installation*" described on *Section 1*.



### NOTE !

The UPS is designed for TN System.

The input neutral shall be grounded at source and shall never be disconnected.

4 pole breaker shall not be used at the UPS input (see also IEC 60634, IEC 61140, IEC 61557).

The cabling of the UPS-system has to be done according to the power installed.

Exceptions are only allowed to suit local prescriptions.

For correct rating of fuses and cable sections for input mains, output load and battery, see data indicated in sections 5.7.2 and 5.7.3.

Before connecting the UPS, verify that the mains voltage and frequency, the output load voltage, the frequency and the battery data (cells number, floating voltage, autonomy) are according to the local requirements.

Protection of the UPS mains input, must be exclusively with 3 pole breakers.

The UPS needs the connection of the Neutral to the input, to guarantee the function in TN mode.

Caution when using **four-pole circuit breakers** as protection to the load of the UPS.

A potential problem exists for situations with non-linear loads: **the neutral current could be greater than the phase currents**.

Avoid to run the input cables in parallel with the output cables to prevent them from noise induction.

The three-phase Mains power supply must be symmetrical with respect to earth, due to the existence of voltage surge protection devices inside the UPS.

The connection of the Battery to the UPS must be protected with fuses or similar devices according to technical specifications and in accordance with local standards.




### NOTE !

In case of non-observance of the required minimum distances on both UPS sides (see *Section 5.4*) it is recommended to provide an additional length of the input/output cables so that the UPS can be moved for maintenance purpose.

It is recommended to use flexible input/output conductors with suitable length to admit a sufficient displacement.

The delivery and installation of fuses and input / output connections of the UPS are at the customer's expense, unless agreed otherwise.



### 5.7.1 Fuse discrimination (co-ordination of breakers tripping)


In order to ensure the circuit selectivity in **case of short- circuit at load level**, special care must be taken in choosing the fuse ratings installed in the output distribution.

When a short-circuit on the output occurs, if the *mains* voltage does not exceed the admitted tolerances, the *load* is instantly transferred to the *mains* through the *automatic bypass*, taking advantage of the higher short circuit power.

To ensure a correct co-ordination of the breakers tripping, the fuses supplying the *bypass* line must be at **least 1,6 time bigger** than the largest fuse in the output distribution.

If the selectivity must be ensured **also in case of mains failure** (that means inhibit *automatic bypass*), the largest fuse in the output distribution must be lower than **20% of the UPS rated current for each phase**.

## 5.7.2 Fuse ratings



### LP33 Series 10 & 20 fuses

The UPS is equipped with “**Rectifier input fuses - F1, F2, F3**” and “**Battery fuses - F9, F10, F11**”.

In case of replacement the same type and the same rating must be used (see table below).

UPS model	Fuses type URD 660/690V F1 - F2 - F3	Fuses type gG-gL 660/690V F9 - F10 - F11
LP33 Series 10	20A (14 x 51)	25A (14 x 51)
LP33 Series 20	40A (14 x 51)	50A (14 x 51)

### Required protective devices

If ELCB breakers are prescribed to protect the input connections, consider the high leakage current towards the earth generated by the noise-suppressor capacitors.

If strongly prescribed, the ELCB breakers should be the largest type suitable for non-linear current and for delayed operation.




Fig. 5.7.2-2 Common input mains




Fig. 5.7.2-3 Separated input mains (option)

UPS model	Fuses (gL) or Circuit Breakers rating for AC input 3x380/220V, 3x400/230V, 3x415/240V			
	F1	F2	F3	F4 (external battery)
LP33 Series 10	3 x 25A	3 x 25A	3 x 20A	3 x 25A
LP33 Series 20	3 x 50A	3 x 50A	3 x 35A	3 x 50A

### 5.7.3 Input / output cable ratings

Cables size indicated below do not consider a possible line voltage.



#### NOTE !

The values given in the tables below do correspond to European Standards (EN) and, in brackets, for Swiss standards.

In any case the local standards must be respected.




Fig. 5.7.3-1 Common input mains




Fig. 5.7.3-2 Separate input mains (option)

UPS model	Recommended sizing for the lines A, B, C, D, E (mm <sup>2</sup> )				
	According to European Standards EN and Swiss standard (in brackets)				
	A and B	C	D	E	K
LP33 Series 10	5 × 4 (5 × 6)	5 × 4 (5 × 6)	4 × 2.5 (4 × 4)	5 × 2.5 (5 × 4)	4 × 4 (4 × 6)
LP33 Series 20	5 × 10 (5 × 16)	5 × 10 (5 × 16)	4 × 6 (4 × 10)	5 × 6 (5 × 10)	4 × 10 (4 × 16)




#### NOTE !

According to EMC standards, the connection between the UPS and an external battery must be done using a shielded cable!


### 5.7.4 Installation requirements

Typical examples for the connection of the LP33 Series 10 & 20.


*Single UPS with common input for rectifier & bypass*




*Single UPS with separate input for rectifier & bypass (option)*



*UPS Parallel System with common input rectifier & bypass*



*UPS Parallel System with separate input for rectifier & bypass (option)*



## 5.8 ELECTRICAL CONNECTION



### WARNING !

The connections to and from the UPS must be executed by **QUALIFIED PERSONNEL ONLY**. Refer to the "*Safety prescriptions - Installation*" described on *Chapter 1*. In case of UPS equipped with options or customized parts not covered by this manual, please consult the appropriate technical documentation before proceeding with electrical connections.

### 5.8.1 Power connection with common input mains




Fig. 5.8.1-1 Common input mains

#### Common input mains

The UPS delivered in standard version has **common input mains**.

Only one input line (F1) supplies both *rectifier* and *bypass* input terminals.

Bear in mind that when the mains fuses are opened there is a supply failure to the *rectifier* as well as to the *automatic bypass* and *manual bypass*.

#### Access to the AC terminals

- 1 - Open the front door "A" of the cabinet.
- 2 - Remove the front panel "B" loosening the screw "D".
- 3 - Remove the left side panel "C" loosening the screws "E".
- 4 - Cut an opening into rubber "F" to allow cable passage.




Fig. 5.8.1-2 Power IN / OUT connections



### NOTE !

For UPS correct operation, the input mains phase rotation must be clock-wise.




Fig. 5.8.1-3 Common input mains connection

#### Input mains connection

- L1** = Phase L1 rectifier + bypass
- L2** = Phase L2 rectifier + bypass
- L3** = Phase L3 rectifier + bypass
- N1** = Neutral mains
- PE** = Earth mains

#### Output load connection

- L1** = Phase L1 load
- L2** = Phase L2 load
- L3** = Phase L3 load
- N2** = Neutral load
- PE** = Earth load



### NOTE !

Input/output terminals must be tightened with a proper screwdriver applying torsion force 1,2 / 1,4 Nm. Clamp the input/output cables with the included cable-ties "G".

## 5.8.2 Power connection with separate input mains (option)




Fig. 5.8.2-1 Separate input mains (option)

### Separate input mains

On request, the UPS can be delivered for **separate input mains**.

Two independent lines (F2 and F3) supply separately the *rectifier* and the *bypass* inputs

With this configuration, when the *rectifier-input* fuses are opened, the *automatic bypass* and the *maintenance bypass* are supplied by the other line.

### Access to the AC terminals

- 1 - Open the front door "A" of the cabinet.
- 2 - Remove the front panel "B" loosening the screw "D".
- 3 - Remove the left side panel "C" loosening the screws "G".
- 4 - Cut an opening into rubber "F" to allow cable passage.




Fig. 5.8.2-2 Power IN / OUT connections

**NOTE !**

Neutral of *rectifier* input and neutral of *bypass* input must be coming from the same input bar.

Inside the UPS, neutrals N1 and N are connected together.




Fig. 5.8.2-3 Separated input mains

**NOTE !**

Input/output terminals must be tightened with a proper screwdriver applying torsion force 1,2 / 1,4 Nm.

Clamp the input/output cables with the included cable-ties "G".

### Rectifier input mains connection

L1 = Phase L1 rectifier

N1 = Neutral mains

L2 = Phase L2 rectifier

PE = Earth mains

L3 = Phase L3 rectifier

### Bypass input mains connection

L1 = Phase L1 bypass

N = Neutral mains

L2 = Phase L2 bypass

L3 = Phase L3 bypass

### Output load connection

L1 = Phase L1 load

N2 = Neutral load

L2 = Phase L2 load

PE = Earth load

L3 = Phase L2 load

**NOTE !**

For UPS correct operation, the input mains phase rotation must be clock-wise.


### 5.8.3 External battery connection

Before proceeding to an external battery connection, follow the **Safety rules** concerning the battery. Make sure that the UPS is not powered, and remove the external battery protections and the **"Battery fuses - F9, F10, F11"** at the front of the UPS cabinet.



#### WARNING !

Before closing the **"Battery fuses - F9, F10, F11"**, verify for correct polarity of the battery connection.



**F9 (+)** = Positive pole

**F10 (0)** = Central point of battery blocks

**F11 (-)** = Negative pole

Fig. 5.8.3-1 External battery connection to UPS



#### NOTE !

Clamp the input/output cables with the included cable-ties "G".

## 5.8.4 RPA system - Control bus connection



### WARNING !

This operation must be performed by trained personnel before the initial start-up (ensure that the UPS installation is COMPLETELY POWERED DOWN).




Fig. 5.8.4-1 Access to the RPA board

### Access to the RPA board

- 1 - Open the front door "A" of the cabinet.
- 2 - Remove the protection covers "B, C, D" loosening the screws "E".



### NOTE !

When fixing again the protection covers, make sure that the screws "E" are as tight as possible since they serve also as earth connection.




Fig. 5.8.4-2 Bus connection RPA Parallel System

### Bus connection RPA Parallel System

Connect the control bus cable between the parallel units as indicated in the diagram Fig. 5.8.4-2. Provide that the connectors J3 and J4 are properly fixed with the included screws.




Fig. 5.8.4-3 Connection to Board P16

### NOTE !

The jumper JP1 - JP2 - JP3 must be removed only on the intermediate units, where the connectors J3 and J4 are both inserted.

Do not insert or remove J3 and J4 from the board "P16 - Connector adapter RPA" when the Parallel System is operating.




Fig. 5.8.4-4 Control bus location RPA Parallel System

### Control bus location RPA Parallel System

Place the cables and connect them as indicated in the diagram Fig. 5.8.4-4 following these procedures:

- Fix the *control bus cables* with the appropriate tie-wrap “F”.
- Place the cables between the parallel units in separated protected conduit to avoid they could be accidentally interrupted.
- Put in place the front screens “B, C and D” (Fig. 5.8.4-1) paying attention to not damaging the control bus cables.

It is important to place the units in sequence of their assigned number.

A unit number from **1** to **4** is displayed on the **control panel**.  
This number is also marked inside and outside the packaging.

The standard length of the control bus cable between two parallel unit is **8 m** (26 ft).



#### NOTE !

Connection and commissioning of an additional UPS to an existing Parallel System, must be performed by a service engineer from of your *Service Centre*.


## 5.9 UPS FUNCTIONING AS FREQUENCY CONVERTER

When the UPS **LP33 Series 10 & 20** is delivered as frequency converter (different output frequency with respect to the input frequency), **the automatic bypass and manual bypass functions are disabled**.

Therefore the *load* cannot be transferred to mains in case of overload, short circuit, or inverter failure.

In cases where the UPS needs to be powered down for maintenance purposes, the critical load must also be powered down during this time.

When the set-up parameters of the UPS are set for *frequency converter*, the **ECO Mode** operation is automatically disabled.



### WARNING !

In case a UPS delivered as frequency converter should be set on site for UPS standard version, the operation must be performed by a qualified service engineer.

### Notices for installation:

- For UPS with *common AC input* follows the standard procedure described in *Section 5.8.1*.

### Notices for start-up procedures:

- Follow the standard procedure indicated in *Section 8.1*.

### Notices for shut-down procedures:

- Follow the standard procedure indicated in *Section 8.1*.



### NOTE !

The inverter can be turned off only by pressing the *"Total Off"* key.

## 6 SYSTEM HANDLING

### 6.1 CONTROL PANEL



Fig. 6.1-1 Control panel

The *Control Panel*, positioned on the UPS front-top, acts as the UPS user interface and comprises of the following elements:

- *Back lit Graphic Display (LCD) with the following characteristics:*
  - *Multilanguage communication interface:*  
*English, German, Italian, Spanish, French, Finnish, Polish, Portuguese, Czech, Slovakian, Chinese, Swedish, Russian and Dutch.*
  - *Synoptic diagram indicating UPS status.*
- *Command keys and parameters setting.*
- *UPS status control LED.*


## 6.2 TABLE OF FUNCTIONS AND INDICATIONS ON CONTROL PANEL

Inverter



**Key to switch the Inverter ON ( I )**

Inverter




**Key for Inverter shut-down ( O )**

Press key to transfers the *Load* to *Mains*.

Keep pressed for 5 seconds to shut-down the *Inverter*.

This key is also used as the *EPO (Emergency Power Off)* reset.

Total Off



**Key "Total Off"**

The key "*Total Off*" is protected by a transparent cover.

By pressing it, you immediately separate the *UPS* from the *Load*.


It is possible to activate the command "*Total Off*" using the following screen:  
*COMMANDS / REQUEST TOTAL OFF*. See Section 7.5.

**Attention:** "*TOTAL Off*" cannot disconnect the *UPS* from the *Load* with *Q2* closed.

**To reset "Total Off"**

Restore the command "*Total Off*"  
by entering the screen:

*COMMANDS / RESET TOTAL OFF*



**RPA**  
Redundant Parallel  
Architecture

**For Parallel System:** if "*Total Off*" is pressed on one unit connected to the parallel bus (switch *Q1* closed), all the units are separated from the load. The "*Total Off*" reset must be done only on one unit connected to the parallel bus (switch *Q1* closed).



### NOTE !

Special care must be taken in using this command, in order to avoid accidental load disconnection.



### LED Stop Operation (red colour)

It warns about the imminent inverter stop (default parameter = 3 min.) and the consequent load shut-down as result of:

- The *battery* is fully discharged and the *load* cannot be transferred on *mains*.
- Overtemperature or overload condition (>105%) and the *load* cannot be transferred on *mains*.



### LED Alarm (yellow colour)

It blinks when one or more alarm is activated. The internal *buzzer* is *ON*.

The *LED* remains lighted (with the alarm condition still present) and the buzzer stops when the key "MUTE" is pressed.

*LED Alarm* is lit when the *load* is not protected by *UPS* or in case *Q1* is open.



### LED Operation (green colour)

When lit, indicates that the *UPS* is functioning correctly and the *load* is system protected (*Load* supplied either from *inverter* or from *Automatic Bypass* in case of *ECO Mode* functionality).

When blinking, indicates that a regular maintenance service is needed (*SERVICE REQUIRED*).

May be reset by a service technician only.

See *Section 11 – Maintenance – Service check*.

The *LED* is *OFF* when the output switch *Q1* is open, indicating that the *Inverter* is in *service mode*, not supplying the *load*.




Fig. 6.2-1 User LCD Interface - Home screen

### User LCD Interface

The user interface consists of a *Back lit Graphic Display (LCD)* having:

- Synoptic diagram indicating *UPS* status.
- *UPS* operating, *AC* and *DC* metering information.
- History of events (alarms and messages).
- Functionality can be programmed to meet customer needs by changing parameters.
- Operation commands of the *UPS*.

## 6.3 COMMAND SWITCHES AND FUSES




Fig. 6.3-1 Q1 and Q2 switches

Q1 - UPS output switch

Q2 - Manual bypass switch



**NOTE !**

Do not switch ON Q1 and Q2 with *Inverter ON*.




Fig. 6.3-2 Rectifier input fuses

Rectifier input fuses




Fig. 6.3-3 Battery fuses

Battery fuses



**NOTE !**

Mains failure of long duration or low Battery voltage will cause the automatic shut-down of the UPS, thus preventing damage to the Battery.

## 7 LCD SCREEN

### 7.1 HOME SCREEN





Fig. 7.1-1 LCD display

The keys perform the following functions:

<b>METER</b>	METERING	View electric parameters values and statistics of use. See <i>Section 7.2</i> .
<b>ALARM</b>	ALARMS	Shows in chronological order, all the events occurred (alarms, messages, commands, handling, etc.). See <i>Section 7.3</i> .
	MUTE	Key to reset general alarm and buzzer.
<b>SETUP</b>	SETUP	Allows the user to customize some UPS functions to specific requirements and to view UPS identification data. See <i>Section 7.4</i> .
<b>CMDS</b>	COMMANDS	Allows the user to execute UPS operation commands. See <i>Section 7.5</i> .

The *LCD screen*, after 5 minutes of inactivity, shuts down the backlight. To reactivate it, it is sufficient to press any keys.

If the keypad remains inactive for 5 minutes or longer, during the viewing of a screen such as *MEASURES*, *ALARMS*, *SETUP* or *COMMANDS*, the *LCD screen* returns automatically to the main screen.

It is possible to view any key functional description by pushing the key for more than 3 seconds.


Pushing the key "MEASURES" and "ALARMS" together automatically sets the *LCD* communication for "ENGLISH".

LP Series S6 20kVA

UPS Model

UPS series number

UPS nominal rating (kVA)


**Battery level LED**

All LED light indicate a battery autonomy of 100%.

LED A	Fixed:	indicates battery autonomy between 6% and 25%.
	Blinking:	indicates battery autonomy $\leq 5\%$ .
LED A, B		Indicate battery autonomy between 26% and 50%.
LED A, B, C		Indicate battery autonomy between 51% and 99%.
Min:		Battery autonomy time in minutes estimates with actual load.

**Load level LED**

All LED Off indicate a load status at  $\leq 25\%$ .



LED A	Indicates a load level between 26% and 50%.
LED A, B	Indicate a load level between 51% and 75%.
LED A, B, C	Indicate a load level between 76% and 100%.
LED A, B, C, D	Indicate a load level between 101% and 124%.
LED D blinking	Indicates a load level $\geq 125\%$ .








Fig. 7.1-2 LEDs on synoptic diagram

**LEDs on synoptic diagram**

LED 1	Mains rectifier OK
LED 2	Mains bypass OK
LED 3	Rectifier ON
LED 4	Discharging battery
LED 5	Booster ON
LED 6	Charge battery ON
LED 7	Inverter available
LED 8	Inverter ON
LED 9	Q1 closed
LED 10	Automatic bypass ON
LED 11	Manual bypass Q2 ON
LED 12	Load on UPS




**Examples of typical scenarios in the synoptic diagram:****Load supplied by inverter****Load supplied by automatic bypass****Load supplied by manual bypass Q2****Load supplied by battery**

## 7.2 METERING




The *METERING mode* is entered any time the “**METER**” key is pressed.

The *LCD screen* will indicate a series of screenshots showing the measures of all electric parameters like AC, DC and various statistics.

In this mode the keys perform the following functions:

	Return to HOME screen.
	Scrolls backward to the previous screen.
	Scrolls forward to the next screen.

It is possible to view any key functional description by pushing the key for more than 3 seconds.

▶Home\Meter	
BATTERY	
Vp	273 V
Vn	273 V
T	+25° C
Charge level	80 %
Autonomy	10 Min
Charger mode	Off
  	




### Battery data screen

<b>Vp</b>	Voltage of positive (+) battery string.
<b>Vn</b>	Voltage of negative (-) battery string.
<b>T</b>	The temperature of the battery (“SENSOR DISABLE” indicates sensor disabled).
<b>Charge level</b>	The battery charge level.
<b>Autonomy</b>	The estimated backup time with the present load.

**Charger mode** The functionality of *SBM (Superior Battery Management)* can help to reduce the battery recharging time, and improve the lifetime of the battery. Beside the indication of the battery voltage on the display, a letter shows, according to the table below, the operational status of *SBM*:




Abbreviation	Status of charger	Charger voltage	Description
<b>Off</b>	OFF	240Vdc	Battery open circuit voltage
<b>Top</b>	ON	Boost (294Vdc)	Boost charge with new Battery
<b>Float</b>	ON	Floating (273Vdc)	Battery charged
<b>Low</b>	ON	Floating (273Vdc)	Normal charge
<b>Boost</b>	ON	Boost (294Vdc)	Boost charge
<b>Equalize</b>	ON	Boost (294Vdc)	Battery equalization

Access to the Parameters for setting the *SBM* mode is password protected. Please call your *Service Centre*.

▶Home\Meter	
BOOSTER	
f	: 50.0 Hz
L1	: 230 V
L2	: 229 V
L3	: 231 V
Vp	: 400 V
Vn	: 400 V
  	




### Booster data screen

<b>f</b>	The input frequency of the rectifier.
<b>L1</b>	3-phase mains voltage PHASE /NEUTRAL.
<b>L2</b>	
<b>L3</b>	
<b>Vp</b>	Voltage of positive (+) booster string.
<b>Vn</b>	Voltage of negative (-) booster string.

Home\Meter	
MAINS	
f	50 Hz
L1	230 V
L2	229 V
L3	231 V
BYPASS FREE	
  	




### Bypass mains data screen

- f The frequency of the mains.
- L1  
L2  
L3 3-phase mains voltage PHASE /NEUTRAL.
- Bypass Bypass status: FREE / LOCKED.

Home\Meter	
INVERTER	
f	50 Hz
L1	230 V
L2	230 V
L3	230 V
T	OK
SYNCHRONIZED	
  	




### Inverter data screen

- f The output frequency of the *Inverter*.
- L1  
L2  
L3 3-phase output voltage PHASE/NEUTRAL.
- T The temperature of the inverter bridge (OK / MAX).
- The synchronization status of the inverter with respect to mains (Synchronized / Not Synchronized).

Home\Meter	
MODULE LOAD	
L1	: 230 V 15.0 A 50 %
L2	: 230 V 12.0 A 40 %
L3	: 230 V 9.0 A 30 %
LOAD ON INVERTER	
  	




### Module load screen

- ... V Output voltage PHASE/NEUTRAL for each phase.
- ... A The output current as RMS values (RPA: value for each UPS).
- ... % The output load as percentage (RPA: value for each UPS).
- The source of the power supplied to the load.

Home\Meter	
COUNTERS	
Bypass mains failure	: 53
Rectifier mains failure	: 35
Overloads	: 15
InvOperTime [h]	: 2135
UPSOperTime [h]	: 3125
  	

### Statistics screen

- The total number of minor mains faults (bypass mains out of tolerance faults).
- The total number of times a gap of mains in the rectifier has been reordered.
- The total number of detected output overloads.
- The total operating time for the *Inverter* (in hours).
- The total operating time for the UPS (in hours).

Home\Meter	
MAINS	
NUMBER OF FAST TRANSIENTS	
<2ms	>2ms >5ms >10ms
25	20 7 5
ECO MODE RATE = 70 %	
  	

### ECO Mode statistic screen

- This screen is enabled only for a single UPS, not for an *RPA Parallel System*.
- The number of fast transients occurred on the bypass utility on the last seven days.
- The statistic evaluation in % (100= good; 0= bad) of the utility, for the *ECO* mode operation.

## 7.3 ALARMS

The *ALARMS mode* is entered any time the “**ALARM**” key is pressed.

The *LCD* will display a series of screens corresponding to the last **255 events**, two events per screen (LEVEL 1 USER).

In this mode the keys perform the following functions:



Return to HOME screen.



Scrolls backward to the previous screen.



Scrolls forward to the next screen.



Move forward to the following event.




Move back to the following previous event.



Confirm the selection made.

It is possible to view any key functional description by pushing the key for more than 3 seconds.

The events displayed are the standard *GE* events as described in the **Section 7.3.1 - EVENTS (Alarms and Messages)**.




### Alarms screen

#### LEVEL 1 USER

Chronologically view 2 events per screenshot.

#### LEVEL 2 SERVICE

Chronologically view 5 events per screenshot with service related info.



### Screen of user alarms

**NR** Number chronologically assigned to an event (Nr. 255 is the more recent, Nr. 1 is the first).  
Date and exact hour of the moment when the event occurred.

**C** Number of standard GE code of the event and an explicit text describing the event in the selected languages.

**S** Status code of the UPS.

### 7.3.1 Events (alarms and messages)

Each of the following listed events, alarm or message, can be displayed on the *LCD screen*, on a *PC* with the software “*GE Data Protection*” installed or with the monitoring system “*GE Power Diagnostic*”.

*Alarms* and *Messages* are differently specified because the **alarms** are indicating an abnormal functioning of the UPS (which are additionally signalled with the **LED Alarm** and acoustically with the **buzzer**), while the **messages** indicate the various states of operation of the UPS (stored in the events list, but not activating the *LED Alarm* and the *acoustical alarm*).

### 7.3.2 Alarms list

Code	Alarm	Meaning
4000	SETUP VALUES LOST	Parameters are lost and have been replaced with default values.
4001	REGULATION BOARD FAILURE	Voltage supply +/-15Vdc has been detected out of tolerance on the P2 - Mainboard or the programmable circuits are defective.
4100	RECTIFIER FUSES FAILURE	The trip indicator mounted on rectifier input fuses indicates a blown fuse. The rectifier is turned Off (K4 open) and the load will be supplied by the battery.
4102	K4 CLOSING FAILURE	K4 not closed despite a closing command being done. The rectifier is switched OFF.
4103	K4 OPENING FAILURE	K4 not open despite an opening command being done. The rectifier is switched OFF.
4110	RECTIFIER MAINS OUT OF TOLERANCE	Rectifier input mains has been detected out of tolerance (voltage, frequency or phase).
4115	LOW BATTERY VOLTAGE	The battery has been discharged and reached “stop operation” time-out (default 3 minutes), the inverter will be shut down. It restarts automatically only when the battery has recovered energy to ensure min. a “stop operation” time to the actual load.
4116	HIGH BATTERY VOLTAGE	Dangerous high UDC-Voltage. Causes Inverter shut-down. Inverter restarts automatically after return to normal floating voltage.
4118	BATTERY FAULT	During battery test the DC voltage falls under the critical level. If the boost voltage has not been reached within 24 hours, then the charge voltage returns to floating voltage. Battery test is stopped.
4130	TURN ON RECT. OR SHUTDOWN UPS	Rectifier and inverter are OFF. The DC power supply is discharging the battery slowly. Rectifier must be restarted or battery must be disconnected in order to avoid damages.
4140	RECTIFIER CONTROL FAILURE	Rectifier voltage hasn't reached the set value. Probably fault on regulation loop. The DC capacitors are not equally charged (more of 50Vdc of difference). The rectifier is switched OFF.

<b>Code</b>	<b>Alarm</b>	<b>Meaning</b>
<b>4301</b>	INVERTER FUSES FAILURE	Inverter output fuses blown. Signalled by electronic detector. Inverter can be started manually after replacement of fuses.
<b>4304</b>	K7 CLOSING FAILURE	K7 not closed despite a closing command being done. Signalled by auxiliary contact. The load will be supplied by mains.
<b>4305</b>	K7 OPENING FAILURE	K7 not open despite an opening command being done. Signalled by auxiliary contact. The load will be supplied by mains.
<b>4312</b>	INV. VOLTAGE OUT OF TOLERANCE	Inverter output voltage is out of the tolerances defined in respective parameter ( $\pm 10\%$ ). Inverter is switched OFF.
<b>4320</b>	ISMAX DETECTION	Detection of inverter bridge (Is) current limitation cause inverter OFF and automatic restart (message 320). After 3 times inverter switches OFF for persistent Is max detection in time. Inverter switch OFF, and it can be restarted manually.
<b>4340</b>	INVERTER CONTROL FAILURE	The slave oscillator is not synchronised with the master, thus causing the shut-down of it's inverter.
<b>4347</b>	OSCILLATOR FAILURE	Auto calibration of the Inverters freerun frequency was not possible. The oscillator frequency of this unit is out of tolerance.
<b>4402</b>	RECTIFIER CANNOT BE TURNED ON	The rectifier cannot be turned on because the DC link voltage has not reached the requested value.
<b>4404</b>	K6 CLOSING FAILURE	K6 not closed despite a closing command being done. Signalled by auxiliary contact. The load cannot be supplied by electronic bypass.
<b>4405</b>	K6 OPENING FAILURE	K6 not open despite an opening command being done. Signalled by auxiliary contact.
<b>4410</b>	BYPASS MAINS OUT OF TOLERANCE	The mains bypass voltage is out of the tolerances ( $\pm 10\%$ ). K6 opens, synchronisation with mains is inhibited and transfer to mains is blocked.
<b>4520</b>	NO INVERTER POWER	The load supplied by utility is over 100%. The load remains blocked on utility as long as alarm overload is active.
<b>4530</b>	LOAD LOCKED ON MAINS	Load is locked on mains because 3 transfers on mains have been detected in a short time (default 30 seconds). Transfer will be free again after a time defined by respective parameter (default 30 seconds).
<b>4531</b>	LOAD ON MAINS BY ERROR DETECTOR	Load is transferred to mains because the error detector detected a disturbance on the output voltage.
<b>4563</b>	EMERGENCY OFF ACTIVATED	Alarm after detection of an Emergency Off from an external safety device connected on Customer Interface. Consequently K4, K6 and K7 open and shut down inverter, booster and rectifier.
<b>4570</b>	OVERLOAD	The UPS-System is in an overload condition $>105\%$ on inverter, or $>150\%$ on mains. A sequence of "stop operation" starts. Time out depending on load quantity.

<b>Code</b>	<b>Alarm</b>	<b>Meaning</b>
<b>4571</b>	OVERLOAD: LOAD ON MAINS	With mains bypass supply available and load >115%, the load is transferred on mains. Load will be transferred again automatically on inverter when load will be <100%.
<b>4581</b>	INVERTER AND MAINS NOT SYNCHRONIZED	The voltages of mains and inverter are not synchronised, which causes the opening of K6.
<b>4697</b>	BATTERY OVERTEMPERATURE	The battery temperature exceeds the value inserted in parameter. Disabled with parameter (service only).
<b>4698</b>	BATTERY POWER INSUFFICIENT	In case of utility failure, with the actual load, the autonomy time would result below "stop operation" time (default 3 minutes).
<b>4700</b>	DC LOW	Battery voltage is at the lowest limit. Shut-down of inverter until the battery voltage reaches the value in respective parameter.
<b>4900</b>	LOAD LOCKED ON INVERTER	The load is locked on Inverter following 3 load transfers within 30 seconds. After time out of the value in respective parameter (default 30 seconds), bypass will be free.
<b>4955</b>	OVERTEMPERATURE	An overtemperature condition has been detected on inverter. Elapsed "stop operation" time, inverter shut-down. With mains available, load is transferred on mains.
<b>4998</b>	LOAD OFF DUE TO EXTENDED OVERLOAD	Load Off after time-out of "stop operation" for overload on inverter (time depending on the % of overload).
<b>4999</b>	LOAD OFF DUE TO LOW BATT. OR TEMP.	Load Off after time-out of "stop operation" with missing mains due to battery low voltage or overtemperature condition.

### 7.3.3 Messages list

Code	Message	Meaning
4111	RECTIFIER MAINS OK	Rectifier input mains is again within the admitted tolerance (voltage, frequency and phase).
4114	UPS SHUTDOWN (LOW BATTERY VOLTAGE)	The UPS is in Load OFF status, resulting in Battery supply for the power supply. Should the Battery voltage decrease to a value below of the one set in a parameter, then power supply will shut-down to avoid damage to the Battery
4119	BATTERY TEST STARTED	Start of manual or automatic battery test. Rectifier output voltage is decreased to the value defined by respective parameter.
4120	BATTERY TEST STOPPED	End battery test. End of manual or automatic battery test. Rectifier output voltage is restored to floating voltage.
4141	ISMAX DETECTION RECTIFIER	Detection of persistent booster (Is) current limitation.
4161	RECTIFIER ON	Rectifier received the command to switch ON.
4162	RECTIFIER OFF	Rectifier received the command to switch OFF for: input mains out of tolerance / EPO / UDC max.
4163	GENERATOR ON	Customer Interface (X1 / 11, 22) received a Gen set ON signalling. Operating mode dependent on setting of respective parameters.
4164	GENERATOR OFF	Customer Interface (X1 / 11, 22) received a Gen set OFF signalling. Function bypass enabled dependent on setting of respective parameter.
4302	INVERTER CANNOT BE TURNED ON	Inverter cannot be switched on because one of the following conditions are still present: <ul style="list-style-type: none"> <li>- <i>Overtemperature</i></li> <li>- <i>Low battery voltage</i></li> <li>- <i>Inverter fuses</i></li> <li>- <i>Overload</i></li> <li>- <i>K7 opening failure</i></li> <li>- <i>High battery voltage</i></li> <li>- <i>DC low</i></li> <li>- <i>EPO (Emergency Power Off)</i></li> </ul>
4303	INVERTER CANNOT BE TURNED OFF	Inverter cannot be switched OFF, because the load cannot be transferred on mains (voltage out of tolerance, not synchronising, bypass blocked).
4361	INVERTER ON	The command to start the inverter has been activated on the control panel.
4362	INVERTER OFF	The command to switch OFF the inverter has been done by the control panel or automatically for alarm detection.
4411	BYPASS MAINS OK	Bypass input mains is again within the admitted tolerance (voltage, frequency and phase).
4500	COMMAND TOTAL OFF	Disconnection of the load by opening K4, K6 and K7 for: EPO / Total Off / Overload / Stop operation.
4521	NO BYPASS POWER	With the load supplied by electronic bypass, a mains failure or K6 opening occurred.
4534	MULTIPLE LOAD TRANSFER	2 transfers inverter-mains have been detected in a short time, defined by respective parameter (default 30 seconds).

<b>Code</b>	<b>Message</b>	<b>Meaning</b>
<b>4535</b>	BYPASS LOCKED	Transfer on mains not enabled due to settings of respective parameters. Contactor K6 is open.
<b>4536</b>	BYPASS FREE	Settings of respective parameters enable bypass transfer on mains. Contactor K6 can be closed.
<b>4561</b>	TOTAL OFF	Key Total Off behind the front door has been pressed, with the output circuit breaker Q1 closed.
<b>4562</b>	DETOUR ON	The auxiliary contact indicates that manual bypass Q2 has been closed.
<b>4564</b>	DETOUR OFF	The auxiliary contact indicates that manual bypass Q2 has been opened.
<b>4567</b>	COMMAND LOAD ON MAINS	The control unit received a command to transfer the load on mains.
<b>4568</b>	COMMAND LOAD ON INVERTER	The control unit received a command to transfer the load on inverter.
<b>4572</b>	NO MORE OVERLOAD	End of the overload condition previously detected with alarm 4570.
<b>4580</b>	INVERTER AND MAINS SYNCHRONIZED	The voltages of inverter and mains bypass are synchronised.
<b>4582</b>	COMMAND NOT TO SYNCHRONIZE	Command not to synchronise with mains has been done for: mains bypass out of tolerance (4410) or setting respective parameters.
<b>4583</b>	COMMAND TO SYNCHRONIZE	Command to synchronise with mains has been done for: mains BP OK (4410) or setting respective parameters.
<b>4600</b>	COMMAND UPS ON	The <i>ECO Mode</i> function has been disabled or the programmed time is expired. The UPS returns to <i>VFI</i> mode supplying the load normally by inverter.
<b>4601</b>	COMMAND UPS STANDBY	The function <i>ECO Mode</i> is enabled, and according to the time program the UPS will run in <i>ECO Mode</i> , supplying the load normally by mains.
<b>4602</b>	Q1 OPEN	The auxiliary contact indicates that the output switch Q1 has been opened.
<b>4603</b>	Q1 CLOSED	The auxiliary contact indicates that the output switch Q1 has been closed.
<b>4699</b>	BATTERY TEST IMPOSSIBLE	Not possible to start battery test (it is postponed) for: - <i>No mains rectifier or bypass</i> - <i>Battery not fully charged</i> - <i>Load is below 10% or above 80%</i>
<b>4763</b>	REMOTE CONTROL ON	Inverter can be started or shut-down by remote control. Commands source can be chosen depending on the value of respective parameter (password required): 0 = <i>Only local panel</i> 1 = <i>Only Remote Control</i> 2 = <i>Both</i>
<b>4764</b>	REMOTE CONTROL OFF	Inverter can be started or shut-down by remote control. Commands source can be chosen depending on the value of respective parameter (password required): 0 = <i>Only local panel</i> 1 = <i>Only Remote Control</i> 2 = <i>Both</i>

### 7.3.4 Event report LP33 Series 10 & 20

In case of failure or malfunction, before calling the nearest **Service Centre** please note the most important identification data of your UPS and the most recent events displayed.

In order to make the diagnosis easier for our **Diagnostic Centre** we suggest you make a copy of this page, fill it in with the requested data, and send it by fax.

Unit No: \_\_\_\_\_ - \_\_\_\_\_ - \_\_\_\_\_

Series No: .....

UPS rating: ..... kVA


Customer: .....

Place: .....

Date: ..... / ..... / .....

Sent by: .....

1. Record the exact **UPS status** on the panel when the failure appeared.



<b>LED 1</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 2</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 3</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 4</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 5</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 6</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 7</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 8</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 9</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 10</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 11</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LED 12</b>	<input type="checkbox"/> ON	<input type="checkbox"/> OFF
<b>LOAD</b>	.....	%
<b>BATTERY</b>	.....	minutes

Description of repair actions taken:

.....  
 .....  
 .....  
 .....

Actual situation:

.....  
 .....  
 .....  
 .....

Remarks:

.....  
 .....  
 .....  
 .....

2. On the LCD panel, enter the "ALARM" Mode and record the alarms/messages in the list below indicating at least 5 events before the failure time.

**Remark:** exact data and time are very important

Event No.	Event Code	UPS Status	Date	Time h. m. s
255				
254				
253				
252				
251				
250				
249				
248				
247				
246				
245				
244				
243				
242				
241				
240				
239				
238				
237				
236				
235				
234				
233				
232				
231				
230				





## 7.4 SETUP

The *SETUP mode* is entered any time the “**SETUP**” key is pressed.







This screen allows the user to modify some parameters permitting to adapt some functions of the UPS to his/her needs, described as follows.

The *LCD* will display a series of screens containing the user parameters, accessible without password protection.







In this mode the keys perform the following functions:

	Return to HOME screen.
	Scrolls backward to the previous screen.
	Scrolls forward to the next screen.
	Confirm selected choice of USER / SERVICE level.

Description of the keys to set or modify the parameters:

<b>ESC</b>	Allows to exit a selected screen without making any modification.
	Scrolls backward to the previous line.
	Scrolls forward to the next line.
	Allows to access a value to be set or modified.
	Select, on the same line, the following value or letter to set or modify.
	Set or modify the selected value.
	Save the set or modified value and return to the selected screen.

**It is possible to view any key functional description by pushing the key for more than 3 seconds.**

▶Home\Setup	
UPS IDENTIFICATION	
ID	: UPS 0
Model	: LP Series S6 20kVA
S/N	: L6020-0512-x001x
UPS SW Version	: xxx
Display SW Version	: xxx
     	

### UPS identification screen

<b>ID</b>	Number of UPS in the RPA Parallel System (0 for single unit).
<b>Model</b>	UPS model, series number and power range
<b>S/N</b>	The UPS serial number.
<b>UPS SW</b>	The UPS software version.
<b>Display SW</b>	The LCD display software version.

▶Home\Setup

**SETUP**

LEVEL 1 : USER

LEVEL 2 : SERVICE

Home Setup Back Up Arrow

**Setup screen****LEVEL 1 USER**

Displays a sequence of screens with parameters which can be user defined.

**LEVEL 2 SERVICE**

Service only allowed.

At this level the parameters access is protected by a code.

▶Home\Setup\User

**DATE AND TIME**

Date : 15.01.2012

Time : 15:37:25

Home Setup Back Up Arrow

**Date and time screen**

**Date** You can adjust the date of the real time clock existing in the UPS by the means of this parameter. The value you enter is thoroughly checked to be a correct date in the format "DD.MM.YY".

**Hour** You can adjust the time of the real time clock existing in the UPS by means of this parameter. The value you enter is thoroughly checked to be a correct time in the format "HH.MM.SS". The time is specified in 24-hour format.

▶Home\Setup\User

**MODEM**

Enabled : N

Init : BEQV1X3&DOS0=2

Alarm call : N

Delay : 30 sec

Tel 1 : 1

Tel 1 enabled : N

Home Setup Back Up Arrow

**Modem screen 1****Enabled**

You can enable/disable with Y/N the remote control through modem calls by using this parameter. For modem connection, the default setting is for serial port J3 on P4 – Customer Interface.

**Init**

This parameter presents the modem initialisation string. It can be 40 characters long.

When editing this parameter the UPS considers that a blank character terminates the string. If no blank character is found then all 40 characters are used.

**Alarm call**

This Y/N parameter controls the automatic events signalling through modem.

If this parameter is set to Y (Yes) the UPS itself will call the remote location when a new event occurs

**Delay**

This parameter controls the delay between the occurrence of a new event and the modem dialling.

It is useful because since the events typically do not occur isolated but in certain sequences, you can eliminate the need for multiple dial-outs for such a sequence of events.

**Tel 1**

This parameter specifies a *first telephone number* to be used for modem dial-out.

The telephone number has a maximum 40 characters and cannot contain blanks.

If the desired number is shorter than 40 characters, the string will finish with blanks.

**Tel 1 enabled**

This parameter Y/N specifies if the *first telephone number (Tel 1)* will be used for dial-out.

►Home\Setup\User

**MODEM**

Tel 2	:	2	
Tel 2 enabled	:		N
Tel 3	:	3	
Tel 3 enabled	:		N
Tel 4	:	4	
Tel 4 enabled	:		N

Home Setup Back Up Arrow Down Arrow Up

## Modem screen 2

**Tel 2** It records the *second dial-out number*.

**Tel 2 enabled** This parameter Y/N specifies if the *second telephone number* will be used for dial-out.

**Tel 3** It records the *third dial-out number*.

**Tel 3 enabled** This parameter Y/N specifies if the *third telephone number* will be used for dial-out.

**Tel 4** It records the *fourth dial-out number*.

**Tel 4 enabled** This parameter Y/N specifies if the *fourth telephone number* will be used for dial-out.

►Home\Setup\User

**DISPLAY**

UPS name	:	LP Series
Language	:	ENGLISH

Home Setup Back Up Arrow Down Arrow Up

## LCD Display screen

**UPS Name** The user can choose the name of the UPS model shown on the main page (max. 9 characters).

**Language** This parameter allows the choice of language used to display the information.

Valid choices are: *English, German, Italian, Spanish, French, Finnish, Polish, Portuguese, Czech, Slovakian, Chinese, Swedish, Russian and Dutch*.

►Home\Setup\User

**ECO MODE**

		Enabled	:	N		
<b>DAY OF WEEK</b>						
d1	d2	d3	d4	d5	d6	d7
<b>HOURS / DAY</b>						
24	24	12	12	12	12	12

Home Setup Back Up Arrow Down Arrow Up

## ECO MODE screen

This screen is enabled only for a single UPS, not for an *RPA Parallel System*.

### Enabled

This parameter (values Y/N) enables or disables the operation in *ECO Mode*.

If the value is Y and the current time is in the interval for the current day, the *ECO Mode* is active.

The activation / deactivation of *ECO Mode* is indicated each time in the event list.

In order to check the *inverter* function, at least 1 minute of *VFI* mode must be programmed during the week (the Y/N parameter is automatically disabled if this condition is not satisfied).

In case this minimum time in *VFI mode* is not respected, the *ECO Mode* will be disabled.

If the value is N, the UPS is normally operating in *VFI / double conversion mode* at all times.

### DAY OF WEEK (d1 ÷ d7): Enabling time in function of weekdays

For the weekdays from **d1** to **d7** (*Saturday to Friday*) the edit mode (edit day) allows to define time intervals when the UPS is operating in *ECO Mode*.

The hour is given in 24-hour format.

These intervals are defined by:

**ECO Mode START:** The hour of the day after which the *ECO Mode* is enabled.

The *ECO Mode* is enabled until the following *ECO Mode STOP* time is reached (the *ECO Mode STOP* time of the same day if this is later than the *ECO Mode START* time, the *ECO Mode STOP* time of the following day otherwise).

**ECO Mode STOP:** The hour of the day before which the *ECO Mode* is enabled.

The *ECO Mode* is enabled starting from the preceding *ECO Mode START* time (the *ECO Mode START* time of the same day if this is earlier than the *ECO Mode STOP* time, the *ECO Mode START* time of the previous day otherwise).

Identical times for *ECO Mode START* and *ECO Mode STOP* maintain the existing mode only in case the previous command was *ECO Mode START* and the following command will be *ECO Mode STOP*.

### HOURS / DAY:

The number of *ECO Mode* hours per weekday (from **d1** - *Saturday* to **d7** - *Friday*) is displayed in the operation mode parameter window (ceiling value).

To better understand the *ECO Mode* programming modes, some typical examples are shown:

**Example 1** For continuous *ECO Mode* set the *ECO Mode START* times to 00:00 and the *ECO Mode STOP* times to 23:59 for all weekdays, but almost 1 day must have 1 minute of *VFI* programming: i.e **d2 - Sunday** 00:00 to 23:58).

Weekday	d1 - Saturday	d2 - Sunday	d3 - Monday	d4 - Tuesday	d5 - Wednesday	d6 - Thursday	d7 - Friday
<b>ECO Mode START</b>	00:00	00:00	00:00	00:00	00:00	00:00	00:00
<b>ECO Mode STOP</b>	23:59	23:58	23:59	23:59	23:59	23:59	23:59

**Example 2** *ECO Mode STOP before ECO Mode START.*

*ECO Mode START* 18:00, *ECO Mode STOP* 06:00 for weekday **d4 - Tuesday**.

Means that on **d4 - Tuesday** the *ECO Mode* is active between 00:00 and 06:00 and between 18:00 and 23:59.

Weekday	d1 - Saturday	d2 - Sunday	d3 - Monday	d4 - Tuesday	d5 - Wednesday	d6 - Thursday	d7 - Friday
<b>ECO Mode START</b>	00:00	00:00	00:00	18:00	00:00	00:00	00:00
<b>ECO Mode STOP</b>	23:59	23:59	23:59	06:00	23:59	23:59	23:59


**Example 3** *ECO Mode during the night and week-end.*

If the *ECO Mode* must be enabled all nights (**d3 - Monday ÷ d7 - Friday**) between 18:00 in the evening and 06:00 of the following morning and during all Saturday (**d1**) and Sunday (**d2**), the corresponding parameters are:

Weekday	d1 - Saturday	d2 - Sunday	d3 - Monday	d4 - Tuesday	d5 - Wednesday	d6 - Thursday	d7 - Friday
<b>ECO Mode START</b>	00:00	00:00	18:00	18:00	18:00	18:00	18:00
<b>ECO Mode STOP</b>	23:59	23:59	06:00	06:00	06:00	06:00	06:00

**Example 4** If the *ECO Mode* must be enabled on *Monday (d3)* and *Tuesday (d4)* between 18:00 in the evening and 06:00 of the following morning, on *Friday (d7)* between 12:00 and 13:00, during all *Saturday (d1)* and on *Sunday (d2)* until 20:00, the corresponding parameters are.

Weekday	d1 - Saturday	d2 - Sunday	d3 - Monday	d4 - Tuesday	d5 - Wednesday	d6 - Thursday	d7 - Friday
<b>ECO Mode START</b>	00:00	00:00	18:00	18:00	00:00	00:00	12:00
<b>ECO Mode STOP</b>	23:59	20:00	23:59	06:00	06:00	00:00	13:00




In dark colour are displayed the times with *ECO Mode* operation.

The arrows indicate the conditions given by the *ECO Mode START* and *ECO Mode STOP* times introduced with the parameters.

Note that on day **d6 - Thursday** the interval has length 0 (zero), therefore the *ECO Mode* is not enabled on this day.

**Example 5** An equivalent set of parameters for *Example 4* is.

Weekday	d1 - Saturday	d2 - Sunday	d3 - Monday	d4 - Tuesday	d5 - Wednesday	d6 - Thursday	d7 - Friday
<b>ECO Mode START</b>	00:00	00:00	18:00	18:00	06:00	09:00	12:00
<b>ECO Mode STOP</b>	23:59	20:00	18:00	06:00	06:00	09:00	13:00



The *ECO Mode* is active from 18:00 of weekday **d3 - Monday** until 06:00 of weekday **d4 - Tuesday** (as indicated by the *ECO Mode STOP* time of weekday **d4 - Tuesday**).

The *ECO Mode STOP* time of weekday **d3 - Monday** has no effect as it is followed by the *ECO Mode STOP* time of weekday **d4 - Tuesday**.

It can be, without change of meaning, any time between 18:00 and 23:59.

Similarly, the *ECO Mode* is active from 18:00 of weekday **d4 - Tuesday** until 06:00 of weekday **d5 - Wednesday**.

The *ECO Mode START* time of weekday **d5 - Wednesday** has no effect as it is preceded by the *ECO Mode START* time of weekday **d4 - Tuesday**.

It can be, without change of meaning, any time between 00:00 and 06:00.



**NOTE !**

To avoid undesired *ECO Mode* operation, verify:

- Date and Time (first page of parameter).
- *ECO mode* screen how many hours of *ECO Mode* operation have been selected for each day of the week.



**NOTE !**





The *ECO Mode* will become active only if the load is supplied from the inverter.

## 7.5 COMMANDS


The *COMMANDS mode* is entered any time the “**COMMANDS**” key is pressed.

Allows the user to execute UPS operation commands.

In this mode the keys perform the following functions:

	Return to HOME screen.
	Scrolls forward to the next screen.
	Scrolls forward to the next line.
	Confirm the selection made.

It is possible to view any key functional description by pushing the key for more than 3 seconds.



### Commands screen 1

#### LAMP TEST

Signalling *LEDs* test and *buzzer* test (all LED should be lit and blinking and the acoustical alarm should be activated).

#### INVERTER ON


Command to switch the inverter.

#### INVERTER OFF

Command to shut-down the inverter.

#### BOOSTER ON (Service)

Service only allowed.



### Commands screen 2



#### RESET TOTAL OFF

Restore of the command “*Total Off*”.

#### REQUEST TOTAL OFF

Command “*Total Off*”.

Screen sequence to execute the command “*Total Off*”:



As the command procedure of “*Total Off*” is finished the “REQUEST TOTAL OFF” screen appears again.

## 8 OPERATION

### 8.1 PROCEDURES FOR SINGLE LP33 SERIES 10 & 20

#### 8.1.1 Start-up of the LP33 Series 10 & 20




#### WARNING !

Before proceeding to turn on the UPS system, ensure that the AC and DC external isolators are OFF, and prevent their inadvertent operation.  
Ensure that the output load distribution can be powered and all the output isolators are open.

This procedure must be performed for the first start-up following the installation, with the UPS completely switched Off and not powered.

Open the front door and make sure that:

- All the **connections** to the input/output terminals of the UPS have been made correctly.
- The **safety screens** are fixed in their position.
- The switches **Q1** and **Q2** are open (Pos. O) and the "**Rectifier input fuses - F1, F2, F3**" and "**Battery fuses - F9, F10, F11**" are removed.



1. Insert the rectifier "Rectifier input fuses - F1, F2, F3".

2. Switch-ON the mains voltage from the input distribution (both rectifier and bypass if separated).

The UPS performs a **SELFTEST**.

A successful termination of the tests will be indicated with Overall test results "OK".

Commissioning cannot be continued should one or more tests result to be negative.

Please contact in this case your *Service Centre*.

At this stage the electronic power supply is switched ON and the buzzer sounds.

LED 1 (mains rectifier OK) and LED 2 (mains bypass OK) must be lit.

Press "MUTE" key to reset acoustical alarm. LED Alarm remains lit.


#### Overall test results

Test1 OK	Test7 OK
Test2 OK	Test8 OK
Test3 OK	Test9 OK
Test4 OK	Test10 OK
Test5 OK	Test11 OK
Test6 OK	




Continue ►



During the first commissioning *LP33 Series 10 & 20* requests a set-up of the UPS configuration parameters presented in the following screens.

Without such configuration it is not possible to continue with the commissioning procedure.

	<p><b>WARNING !</b></p> <p>The setup of the UPS configuration parameters must be done only by <b>QUALIFIED AND TRAINED PERSONNEL</b>.</p> <p>The setup of mistaken values could compromise the integrity and reliability of the UPS.</p>
---	--

In this mode the keys perform the following functions:



	Confirm the selection made and select the next parameter.
<b>ESC</b>	Re-establish default value.
	Modify or insert the selected value.
	Save the configuration of set parameters.

►Configuration	
<b>DISPLAY CONFIGURATION</b>	
Select language :	<b>ENGLISH</b>
<div> <div>ESC</div> <div></div> <div></div> </div>	

### DISPLAY CONFIGURATION screen

#### Select language

This parameter allows the choice of language used to display the information.

►Configuration	
<b>UPS CONFIGURATION</b>	
Input frequency :	<b>50</b> Hz
Output frequency :	<b>50</b> Hz
Inverter voltage :	<b>230</b> V
<div> <div>ESC</div> <div></div> <div></div> </div>	

### UPS CONFIGURATION screen

#### Input frequency

Input frequency value (\*50Hz).

#### Output frequency

Inverter output frequency value (\*50Hz).

#### Inverter voltage

Output voltage PHASE/NEUTRAL of the inverter (220V/230V/240V).

\*) Configuration of the frequency to 60Hz requires the intervention of a *Service Centre*.

Continue ►

►Configuration

**BATTERY CONFIGURATION**

Type : **Lead Acid**

Float voltage : **273 V**

Recharge current : **002.8 A**

Autonomy time : **010 min**

Stop Operation time : **003 min**

Capacity : **0014 Ah** Cells : **120**

ESC [ ] [ ] [ ] [ ]

**BATTERY CONFIGURATION screen**

Type Battery type (Lead Acid).  
*Lead - Acid* Sealed Battery (VRLA).

**Float voltage**

Voltage to maintain battery charging (insert the value of single battery string).

Float voltage = Number of battery cells × battery float voltage per cell.

Typical battery float voltage per cell (ask the battery manufacturer for confirmation):

*Lead - Acid (VRLA):* 2.27Vdc for cell 120 cells × 2.27Vdc = **273Vdc**

**Recharge current**

Maximum battery recharge current.

Default setting value: 1.4A (10 kVA) 2.8A (20 kVA)

**Autonomy time**

The autonomy time of the battery.

UPS autonomy on battery mode at full load condition.

This value is calculated based on the *battery type, capacity and number of cells*.

Autonomy times for lead acid batteries (VRLA)						
2 x 120 cells		Autonomy at full load at PF=0.8			U floating = 273Vdc (2.27Vdc - cell)	
UPS Model	Battery with expected trickle life 5 years					
	7Ah	14Ah	21Ah	28Ah	35Ah	42Ah
LP33 Series 10	10	25	45	60	80	100
LP33 Series 20	-	10	20	28	37	45

Autonomy time for battery supplied by GE UPS manufacturer.

**Stop Operation time**

Residual battery autonomy time before UPS forced shut-down. Standard set 3 minutes.

Settable from 1 minute to autonomy time in minutes (see tables).


**Capacity**

Ah capacity of the battery.

**Cells**

Number of cells of the battery (insert the value of single battery string).

*Lead - Acid (VRLA):* 120 cells.



**NOTE !**

The values indicated above, must be considered as standard values.  
 The actual programmed values must be the ones defined from the battery manufacturer.

►Configuration

**CONFIGURATION**

Save and exit ?

Yes

[ ] [ ] [ ] [ ]

**CONFIGURATION screen**

Screen to save the configuration of set parameters.

Any additional modification of setup parameters can be done only by a GE SERVICE PERSON as it requires an access code.

Continue ►

### 3. Insert the "Battery fuses - F9, F10, F11" and eventual external fuses in case of external battery.




#### **DANGER !**

Before to perform this operation, check the right DC polarities on both side of the switch/fuse holder!

### 4. Close the output switch Q1 (Pos. II).

The load is supplied by the mains through the *automatic bypass*.

The *synoptic diagram* must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS**".



Verify, selecting the screen *METERING/BOOSTER/Vp* and *Vn*, that the booster voltage has reached about **400Vdc**.


Home\Meter	
BOOSTER	
f	: 50.0 Hz
L1	: 397 V
L2	: 395 V
L3	: 393 V
Vp	: <b>400 V</b>
Vn	: <b>400 V</b>

### 5. Insert the inverter by pressing "Inverter ON" (I) key.

Some seconds later the load will be transferred on *inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *synoptic diagram* must display the status "**LOAD SUPPLIED BY INVERTER**".



### 6. Load supply.

Your LP33 Series 10 & 20 UPS is now running in *VFI mode*, supplying power to the output.

Insert the *loads* one by one to the output of the UPS.

Check the output current value of *L1*, *L2* and *L3* and check for correct load balance.

### 7. Operation mode selection.

LP33 Series 10 & 20 is delivered normally selected for permanent *VFI* operation.

*ECO mode* can be enabled and the *ECO Mode START* time & *ECO Mode STOP* time can be programmed for each day of the week (see *Section 7.4 SETUP / ECO MODE*).

## END OF PROCEDURE



#### **NOTE !**

Even if the UPS is delivered with the *battery* fully charged, they could be partially discharged during transportation or storage.

It is recommended to recharge the battery during at least 10 hours in order to provide the complete *battery* energy stored to the load in the event of *mains failure*.

### 8.1.2 UPS shut-down with load transfer on manual bypass Q2

The purpose of this procedure is to supply the *load* directly by *mains* through **manual bypass Q2**.

This procedure is normally performed when the UPS must be completely switched OFF for maintenance or service purpose, performed by an authorised *Service Centre*.



#### NOTE !


This procedure must not be performed if the UPS is used as *frequency converter*.

1. **Disconnect the inverter by pressing "Inverter OFF" ( O ) key and hold until the LED Inverter (7) turns OFF.**

*Load* is transferred to *mains* by *automatic bypass*.

LED Alarm is lit and the LED Operation is Off.


The *synoptic diagram* must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS**".



2. **Close the manual bypass switch Q2 (Pos. II).**

*Load* is now supplied parallel through *automatic bypass* and *manual bypass Q2*.


The *synoptic diagram* must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS AND MANUAL BYPASS Q2**".



3. **Open the output switch Q1 (Pos. 0).**

The *load* is now supplied only through the *manual bypass Q2*.

The *synoptic diagram* must display the status "**LOAD SUPPLIED BY MANUAL BYPASS Q2**".



4. **Press "Total Off" key.**
5. **Remove the "Rectifier input fuses - F1, F2, F3" and the "Battery fuses - F9, F10, F11" (remove the external battery fuses in case of external battery).**





The *acoustical alarm* is activated, press "**MUTE**" key to reset it.

Continue ►

6. In order to discharge the DC link capacitors, insert the inverter by pressing "Inverter ON" (I) key.





**Remark:**

Command *INVERTER ON* will be enabled only when the *inverter voltage* of each phase decreases below **7Vac** (about 30 seconds).

Home\Meter		
INVERTER		
f	:	50.0 Hz
L1	:	7 V
L2	:	7 V
L3	:	7 V
T	:	OK
SYNCHRONIZED		
   		


Before proceeding to step 7, check on the display panel that the *DC link voltage* (both polarities) **Vp** and **Vn** has reached the max. voltage of **5Vdc** (about 30 seconds).

The *acoustical alarm* is activated, press "MUTE" key (from Home screen) to reset it.

Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	5 V
Vn	:	5 V
   		

7. Disconnect the inverter by pressing "Inverter OFF" (O) key and hold until the LED Inverter (7) turns OFF.

The load is now powered directly by mains through the **MANUAL BYPASS Q2**.



**END OF PROCEDURE**



**WARNING !**

If the above procedure is not completely performed, it could cause serious damages to the UPS.

In case the procedure described on step "6 - Discharge DC link capacitors" cannot be completely performed, the DC capacitors could be charged with dangerous voltage for min. 5 minutes.

The UPS cabinet contains parts electrically live.

Apart from the front door, do not open any other part of the UPS.



**NOTE !**

With separate mains inputs, it's possible to disconnect mains rectifier.

### 8.1.3 From Manual Bypass Q2 to normal function VFI

This procedure presupposes that the *load* is powered by the *manual bypass Q2* switch, and:

- The *inverter* is switched OFF;
- The *manual bypass* switch Q2 is closed (Pos. I);
- The output switch Q1 is open (Pos. 0);
- The “Rectifier input fuses - F1, F2, F3” and “Battery fuses - F9, F10, F11” are removed;
- LED Alarm blinks.



#### NOTE !


This procedure must not be performed if the UPS is used as *frequency converter*.

1. Insert the “Rectifier input fuses - F1, F2, F3” and the “Battery fuses - F9, F10, F11” (insert the external battery fuses in case of external battery).

2. Close the output switch Q1 (Pos. I).


Load is now supplied parallel through *automatic bypass* and *manual bypass Q2*.

The synoptic diagram must display the status “LOAD SUPPLIED BY AUTOMATIC BYPASS AND MANUAL BYPASS Q2”.



3. Only in case it has been previously activated, restore the command “Total Off” by entering the screen:

COMMANDS/RESET TOTAL OFF



4. Open the manual bypass switch Q2 (Pos. 0).

The *load* is supplied by the mains through the *automatic bypass*.

Verify, selecting the screen *METERING/BOOSTER/Vp* and *Vn*, that the booster voltage has reached about **400Vdc**.


Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	400 V
Vn	:	400 V

5. Insert the inverter by pressing “Inverter ON” (I) key.

Some seconds later the *load* will be transferred on *inverter*.

LED Alarm turns Off and the LED Operation must be lit.

The synoptic diagram must display the status “LOAD SUPPLIED BY INVERTER”.



END OF PROCEDURE

### 8.1.4 Complete UPS shut-down

As a result of this procedure the UPS is completely switched OFF and not powered.



#### NOTE !

Follow this procedure only in case the UPS system and the load must be completely powered-down.

1. Press "Total Off" key.
2. Open the output switch Q1 (Pos. 0).
3. Remove the "Rectifier input fuses - F1, F2, F3" and the "Battery fuses - F9, F10, F11" (remove the external battery fuses in case of external battery).  
The acoustical alarm is activated, press "MUTE" key to reset it.
4. In order to discharge the DC link capacitors, insert the inverter by pressing "Inverter ON" (I) key.

#### Remark:

Command *INVERTER ON* will be enabled only when the inverter voltage of each phase decreases below **7Vac** (about 30 seconds).

The *acoustical alarm* is activated, press "MUTE" key (from Home screen) to reset it.

Before proceeding to step 5, check on the display panel that the *DC link voltage* (both polarities) **Vp** and **Vn** has reached the max. voltage of **5Vdc** (about 30 seconds).

Home\Meter		
INVERTER		
f	:	50.0 Hz
L1	:	7 V
L2	:	7 V
L3	:	7 V
T	:	OK
SYNCHRONIZED		

Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	5 V
Vn	:	5 V

5. Disconnect the inverter by pressing "Inverter OFF" (O) key and hold until the LED Inverter (7) turns OFF.
6. Switch OFF the mains power at the AC input distribution panel.

END OF PROCEDURE



#### WARNING !

If the above procedure is not completely performed, it could cause serious damages to the UPS.

In case the procedure described on step "4 - Discharge DC link capacitors" cannot be completely performed, the DC capacitors could be charged with dangerous voltage for min. 5 minutes.

The UPS cabinet contains parts electrically live.

Apart from the front door, do not open any other part of the UPS.

### 8.1.5 Restore to normal operation after "Total Off"




#### NOTE !

Make sure the UPS to be status of the activation of "Total Off", i. e. Q1 closed, Q2 open and the "Rectifier input fuses - F1, F2, F3" and "Battery fuses - F9, F10, F11" connected.

View of the synoptic diagram after pressing the "Total Off" key:

- All Contactors are open.
- *Booster, Inverter and Static-Switch* shut-down.



#### 1. Reset "Total Off".

Restore the command "Total Off" by entering the screen:



COMMANDS / **RESET TOTAL OFF**

LED Alarm is lit.

The load is supplied by the *mains* through the *automatic bypass*.

The *booster* starts automatically.

The *synoptic diagram* must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS**".




#### 2. Insert the inverter by pressing "Inverter ON" (I) key.

Some seconds later the load will be transferred on *inverter*.

LED Alarm turns Off and the LED Operation must be lit.

The *synoptic diagram* must display the status "**LOAD SUPPLIED BY INVERTER**".



**END OF PROCEDURE**

### 8.1.6 Restore to normal operation after "EPO – Emergency Power Off"




#### NOTE !

Make sure the UPS to be status of the activation of "EPO - Emergency Power Off", i. e. Q1 closed, Q2 open and the "Rectifier input fuses - F1, F2, F3" and "Battery fuses - F9, F10, F11" connected.

View of the synoptic diagram after pressing the push-button "EPO - Emergency Power Off":

- All Contactors are open.
- *Booster, Inverter and Static-Switch* shut-down.



#### 1. Reset the "EPO" key.


Press MUTE key to reset Alarm and Acoustical alarm.  
LED Alarm remains lit.

#### 2. Reset the UPS by pressing "Inverter OFF" (O) key.

The load is supplied by the mains through the automatic bypass.

The booster starts automatically.

The synoptic diagram must display the status "LOAD SUPPLIED BY AUTOMATIC BYPASS".




#### 3. Insert the inverter by pressing "Inverter ON" (I) key.

Some seconds later the load will be transferred on inverter.

LED Alarm turns Off and the LED Operation must be lit.

The synoptic diagram must display the status "LOAD SUPPLIED BY INVERTER".



**END OF PROCEDURE**

## 8.2 PROCEDURES FOR LP33 SERIES 10 & 20 PARALLEL SYSTEM

### 8.2.1 LP33 Series 10 & 20 Parallel System start-up




#### WARNING !

Before proceeding to turn on the *UPS Parallel System*, ensure that the AC and DC external isolators are OFF, and prevent their inadvertent operation. Ensure that the output load distribution can be powered and all the output isolators are open.

This procedure must be performed for the first start-up following the installation, with the *UPS Parallel System* completely switched Off and not powered.

Open the front door on all UPS units and make sure that:

- All the **connections** to the input/output terminals of the UPS have been made correctly.
- The **safety screens** are fixed in their position.
- The switches **Q1** and **Q2** are open (Pos. O) and the "**Rectifier input fuses - F1, F2, F3**" and "**Battery fuses - F9, F10, F11**" are removed.



1. Insert the "Rectifier input fuses - F1, F2, F3" on all UPS units.
2. Switch-ON the mains voltage, on all UPS units, from the input distribution (both rectifier and bypass if separated).

The UPS performs a *SELFTEST*.

A successful termination of the tests will be indicated with Overall test results "OK".

Commissioning cannot be continued should one or more tests result to be negative.

Please contact in this case your *Service Centre*.

At this stage the electronic power supply is switched ON and the buzzer sounds.

LED 1 (mains rectifier OK) and LED 2 (mains bypass OK) must be lit.

Press "MUTE" key to reset acoustical alarm. LED Alarm remains lit.


#### Overall test results

Test1 OK	Test7 OK
Test2 OK	Test8 OK
Test3 OK	Test9 OK
Test4 OK	Test10 OK
Test5 OK	Test11 OK
Test6 OK	




Continue ►



During the first commissioning *LP33 Series 10 & 20* requests a set-up of the UPS configuration parameters presented in the following screens.

Without such configuration it is not possible to continue with the commissioning procedure.

	<p><b>WARNING !</b></p> <p>The setup of the UPS configuration parameters must be done only by <b>QUALIFIED AND TRAINED PERSONNEL</b>.</p> <p>The setup of mistaken values could compromise the integrity and reliability of the UPS.</p>
---	--

In this mode the keys perform the following functions:



	Confirm the selection made and select the next parameter.
<b>ESC</b>	Re-establish default value.
	Modify or insert the selected value.
	Save the configuration of set parameters.

► Configuration	
DISPLAY CONFIGURATION	
Select language :	<b>ENGLISH</b>
<div>ESC</div> <div></div> <div></div>	

### DISPLAY CONFIGURATION screen

#### Select language

This parameter allows the choice of language used to display the information.

► Configuration	
UPS CONFIGURATION	
Input frequency :	<b>50</b> Hz
Output frequency :	<b>50</b> Hz
Inverter voltage :	<b>230</b> V
<div>ESC</div> <div></div> <div></div>	

### UPS CONFIGURATION screen

#### Input frequency

Input frequency value (\*50Hz).

#### Output frequency

Inverter output frequency value (\*50Hz).

#### Inverter voltage

Output voltage PHASE/NEUTRAL of the inverter (220V/230V/240V).

\*) Configuration or change of the frequency to 60Hz requires the intervention of a *Service Centre*.

Continue ►

Configuration			
<b>BATTERY CONFIGURATION</b>			
Type	:	Lead Acid	
Float voltage	:	273 V	
Recharge current	:	002.8 A	
Autonomy time	:	010 min	
Stop Operation time	:	003 min	
Capacity	:	0014 Ah	Cells : 120
ESC			

**BATTERY CONFIGURATION screen**

Type Battery type (Lead Acid).  
*Lead - Acid* Sealed Battery (VRLA).

**Float voltage**

Voltage to maintain battery charging (insert the value of single battery string).

Float voltage = Number of battery cells x battery float voltage per cell.

Typical battery float voltage per cell (ask the battery manufacturer for confirmation):

*Lead - Acid (VRLA):* 2.27Vdc for cell 120 cells x 2.27Vdc = **273Vdc**

**Recharge current**

Maximum battery recharge current.

Default setting value: 1.4A (10 kVA) 2.8A (20 kVA)

**Autonomy time**

The autonomy time of the battery.

UPS autonomy on battery mode at full load condition.

This value is calculated based on the *battery type, capacity and number of cells*.

Autonomy times for lead acid batteries (VRLA)						
2 x 120 cells		Autonomy at full load at PF=0.8			U floating = 273Vdc (2.27Vdc - cell)	
UPS Model	Battery with expected trickle life 5 years					
	7Ah	14Ah	21Ah	28Ah	35Ah	42Ah
LP33 Series 10	10	25	45	60	80	100
LP33 Series 20	-	10	20	28	37	45

Autonomy time for battery supplied by GE UPS manufacturer.

**Stop Operation time**

Residual battery autonomy time before UPS forced shut-down. Standard set 3 minutes.

Settable from 1 minute to autonomy time in minutes (see tables).


**Capacity**

Ah capacity of the battery.

**Cells**

Number of cells of the battery (insert the value of single battery string).

*Lead - Acid (VRLA):* 120 cells.

	<p><b>NOTE !</b></p> <p>The values indicated above, must be considered as standard values.  The actual programmed values must be the ones defined from the battery manufacturer.</p>
---	--

Configuration			
<b>CONFIGURATION</b>			
Save and exit ?			
Yes			

**CONFIGURATION screen**

Screen to save the configuration of set parameters.

Any additional modification of setup parameters can be done only by a GE SERVICE PERSON as it requires an access code.

Continue ►

3. **Insert the "Battery fuses - F9, F10, F11" and eventual external fuses in case of external battery on all UPS units.**




**DANGER !**

Before to perform this operation, check the right DC polarities on both side of the switch/fuse holder!

4. **Close the output switch Q1 (Pos. I) on all UPS units.**

When the last Q1 will be closed the output will be supplied by the mains through all *automatic bypass*.

The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY AUTOMATIC BYPASS"**.



Verify on all UPS units, selecting the screen *METERING/BOOSTER/Vp* and *Vn*, that the booster voltage has reached about **400Vdc**.


Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	400 V
Vn	:	400 V

5. **Insert the inverter by pressing "Inverter ON" (I) key on first UPS unit.**

In case of sufficient output power, the output will transfer to *Inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *synoptic diagram*, on first UPS unit, must display the status **"LOAD SUPPLIED BY INVERTER"**.




6. **Insert the inverter by pressing "Inverter ON" (I) key on all other UPS units.**

Do not start the next *inverter* until the sequence of the previous one ends.

As soon as the output power of the *inverters* is sufficient to supply the *load*, the output of the units with running *inverter* will transfer to *inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY INVERTER"**.



7. **Load supply.**

*LP33 Series 10 & 20 Parallel System* is now running, supplying power to the output.

Insert the *loads* one by one to the output of the *LP33 Series 10 & 20 Parallel System*.

Check the output current value of *L1*, *L2* and *L3* and check for correct load balance.

**END OF PROCEDURE**



**NOTE !**

Even if the UPS is delivered with the *battery* fully charged, they could be partially discharged during transportation or storage.


It is recommended to recharge the battery during at least 10 hours in order to provide the complete *battery* energy stored to the load in the event of *mains failure*.

## 8.2.2 Parallel UPS shut-down with load transfer on manual bypass Q2

The purpose of this procedure is to supply the *load* directly by *mains* through **manual bypass Q2**.

This procedure is normally performed when the *System Parallel* must be completely switched OFF for maintenance or service purpose, performed by an authorised *Service Centre*.

The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY INVERTER"**.




1. **Disconnect the inverter by pressing "Inverter OFF" ( O ) key and hold until the LED Inverter (7) turns OFF on all UPS units.**

The output will be supplied by the mains through all *automatic bypass*.

LEDs Alarm are lit and the LEDs Operation are Off.


The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY AUTOMATIC BYPASS"**.



2. **Close the manual bypass switch Q2 (Pos. I) on all UPS units.**

Load is now supplied from *mains* in parallel from *automatic bypass* and *manual bypass Q2* of all UPS units.


The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY AUTOMATIC BYPASS AND MANUAL BYPASS Q2"**.



3. **Open the output switch Q1 (Pos. 0) on all UPS units.**

The *load* is now supplied only through the *manual bypass Q2*.

The *synoptic diagram*, on all UPS units, must display the status **"LOAD SUPPLIED BY MANUAL BYPASS Q2"**.



4. **Press "Total Off" key on all UPS units.**

5. **Remove the "Rectifier input fuses - F1, F2, F3" and the "Battery fuses - F9, F10, F11" (remove the external battery fuses in case of external battery) on all UPS units.**




The *acoustical alarm* is activated, press **"MUTE"** key to reset it.

Continue ►

6. In order to discharge the DC link capacitors, insert the inverter by pressing "Inverter ON" (I) key on all UPS units.




**Remark:**

Command *INVERTER ON* will be enabled only when the inverter voltage of each phase decreases below **7Vac** (about 30 seconds).

Home\Meter		
INVERTER		
f	:	50.0 Hz
L1	:	7 V
L2	:	7 V
L3	:	7 V
T	:	OK
SYNCHRONIZED		
  		

Before proceeding to step 7, check on the display panel that the DC link voltage (both polarities) **Vp** and **Vn** has reached the max. voltage of **5Vdc** (about 30 seconds).


The *acoustical alarm* is activated, press "MUTE" key (from Home screen) to reset it.

Home\ Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	5 V
Vn	:	5 V
  		

7. Disconnect the inverter, on all UPS units, by pressing "Inverter OFF" (O) key and hold until the LED Inverter (7) turns OFF.

The load is now powered directly by mains through all **MANUAL BYPASS Q2**.

The *synoptic diagram*, on all UPS units, must display the status "**LOAD SUPPLIED BY MANUAL BYPASS Q2**".



### END OF PROCEDURE

**WARNING !**

If the above procedure is not completely performed, it could cause serious damages to the UPS.

In case the procedure described on step "6 - Discharge DC link capacitors" cannot be completely performed, the DC capacitors could be charged with dangerous voltage for min. 5 minutes.

The UPS cabinet contains parts electrically live.

Apart from the front door, do not open any other part of the UPS.

**NOTE !**


With separate mains inputs, it's possible to disconnect mains rectifier.

### 8.2.3 From Manual Bypass Q2 to normal function VFI

This procedure presupposes that the *load* is powered by all *manual bypass Q2* switch of the *Parallel System*, and:

- The *inverter* is switched OFF;
- The *manual bypass* switch Q2 is closed (Pos. I);
- The output switch Q1 is open (Pos. 0);
- The “*Rectifier input fuses - F1, F2, F3*” and “*Battery fuses - F9, F10, F11*” are removed.
- *LED Alarm* blinks.


The *synoptic diagram*, on all UPS units, must display the status “**LOAD SUPPLIED BY MANUAL BYPASS Q2**”.




1. **Insert the “Rectifier input fuses - F1, F2, F3” and the “Battery fuses - F9, F10, F11” (and eventual external battery fuses) on all UPS units.**
2. **Close the output switch (Pos. I) on all UPS units.**

When the last Q1 will be closed the output will be from *mains* in parallel from *automatic bypass* and *manual bypass Q2* of all UPS units.

The *synoptic diagram*, on all UPS units, must display the status “**LOAD SUPPLIED BY AUTOMATIC BYPASS AND MANUAL BYPASS Q2**”.



3. Only in case it has been previously activated, restore the command “*Total Off*” **on any one of the units** by entering the screen: **COMMANDS/RESET TOTAL OFF**



4. **Open the manual bypass switch Q2 (Pos. 0) on all UPS units.**

The *load* is supplied by the *mains* through the *automatic bypass*.

Verify on all UPS units, selecting the screen **METERING/BOOSTER/Vp** and **Vn**, that the *booster voltage* has reached about **400Vdc**.


Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	400 V
Vn	:	400 V

5. **Insert the inverter by pressing “Inverter ON” (I) key on first UPS unit.**

In case of sufficient output power, the output will transfer to *Inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *synoptic diagram*, on first UPS unit, must display the status “**LOAD SUPPLIED BY INVERTER**”.




6. **Insert the inverter by pressing “Inverter ON” (I) key on all other UPS units.**

Do not start the next *inverter* until the sequence of the previous one ends.

As soon as the output power of the *inverters* is sufficient to supply the *load*, the output of the units with running *inverter* will transfer to *inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *synoptic diagram*, on all UPS units, must display the status “**LOAD SUPPLIED BY INVERTER**”.



**END OF PROCEDURE**

### 8.2.4 Separate a UPS unit from the Parallel System (System Redundancy)

One UPS unit of the *Parallel System* has to be turned Off, while the *load* is shared between the other units supplying the parallel bus.

1. **Disconnect the inverter, only on this unit, by pressing "Inverter OFF" ( O ) key and hold until the LED Inverter (7) turns OFF.**

With *redundant system*, pressing the key OFF the *inverter* shuts down and it will stay OFF.

If by pressing the key "O" the *load* is transferred to the *mains* and the *inverter* remains operating, it means the system is not redundant.

In this case is not possible to switch-OFF one unit without transferring the *load* on *mains*.

*Load* supplied from *inverter(s)* of the other Unit(s) of the *Parallel System*.


2. **Open the output switch Q1 only on this unit.**

LED Alarms is lit and the LED Operation is Off.

3. **Perform the command "Total Off" only on this unit.**

Perform the command "Total Off" by entering the screen (see Section 7.5):


COMMANDS / REQUEST TOTAL OFF



4. **Remove the "Rectifier input fuses - F1, F2, F3" and the "Battery fuses - F9, F10, F11" (remove the external battery fuses in case of external battery) only on this unit.**
5. **In order to discharge the DC link capacitors, insert the inverter by pressing "Inverter ON" ( I ) key only on this unit.**


**Remark:**

Command *INVERTER ON* will be enabled only when the inverter voltage of each phase decreases below **7Vac** (about 30 seconds).



Before proceeding to step 6, check on the display panel that the *DC link voltage* (both polarities) **Vp** and **Vn** has reached the max. voltage of **5Vdc** (about 30 seconds).

The *acoustical alarm* is activated, press "MUTE" key (from Home screen) to reset it.



6. **Disconnect the inverter, only on this unit, by pressing "Inverter OFF" ( O ) key and hold until the LED Inverter (7) turns OFF.**
7. **Switch OFF the mains power, only on this unit, at the AC input distribution panel.**

**END OF PROCEDURE**



**WARNING !**

In case the unit should be disconnected and removed from the operating system, the operation **MUST BE PERFORMED BY QUALIFIED PERSONS**.

If an intermediate unit must be disconnected from a *Parallel System* pay attention do not open the control bus: keep the plugs *J3* and *J4* connected to the board "*P16 - Connector adapter RPA*" (see Section 5.8.4).

For any further intervention contact nearest *Service Centre*.

## 8.2.5 Reconnect a UPS unit to a Parallel System



### WARNING !

Before connecting hazardous voltages, make sure that:

- The connection to the electrical system has been performed by qualified personnel;
- The *equipment frame* has been correctly grounded to the *main earth*;
- Make sure that *mains input* protection is removed;
- All the *panels* removed to allow the UPS connection have been correctly reinstalled;
- The UPS switches Q1 and Q2 are open (Pos. 0);
- The "Rectifier input fuses - F1, F2, F3" and "Battery fuses - F9, F10, F11" is removed.

This procedure must be performed when the *load* is supplied by the other units of the *UPS Parallel System* and an additional unit must be switched ON and connected to the parallel bus in order to share the load with each other.

This unit must be completely switched OFF and not powered.

1. Insert the "Rectifier input fuses - F1, F2, F3" on this UPS unit.
2. Switch-ON the mains voltage from the input distribution (both rectifier and bypass if separated) on this UPS unit.

The UPS performs a *SELFTTEST*.

A successful termination of the tests will be indicated with Overall test results "OK".

Commissioning cannot be continued should one or more tests result to be negative.

Please contact in this case your *Service Centre*.

Overall test results	
Test1 OK	Test7 OK
Test2 OK	Test8 OK
Test3 OK	Test9 OK
Test4 OK	Test10 OK
Test5 OK	Test11 OK
Test6 OK	

3. Insert the "Battery fuses - F9, F10, F11" (insert the external battery fuses in case of external battery) on this UPS unit.
4. Close output switch Q1 (Pos. I) on this UPS unit.

Verify on this UPS unit, selecting the screen *METERING/BOOSTER/Vp* and *Vn*, that the booster voltage has reached about **400Vdc**.


Home\Meter	
BOOSTER	
f	: 50.0 Hz
L1	: 397 V
L2	: 395 V
L3	: 393 V
Vp	: 400 V
Vn	: 400 V

5. Insert the inverter by pressing "Inverter ON" (I) key on this UPS unit.

When the *inverter* will be synchronised, the unit will be automatically connected with the *parallel bus-bar* and the *load* will be shared with the other units.

LED Alarm turns Off and the LED Operation must be lit.

The *synoptic diagram*, on all UPS units, must display the status "LOAD SUPPLIED BY INVERTER".



**END OF PROCEDURE**

## 8.2.6 Complete Parallel System shut-down

As a result of this procedure the *Parallel System* is completely switched OFF and not powered.



### NOTE !

Follow this procedure only in case the *Parallel System* and the load must be completely powered-down.

1. Press "Total Off" key on anyone of the parallel units.
2. Open the output switch Q1 (Pos. 0) on all UPS units.
3. Remove the "Rectifier input fuses - F1, F2, F3" and the "Battery fuses - F9, F10, F11" (remove the external battery fuses in case of external battery) on all UPS units.

The *acoustical alarm* is activated, press "MUTE" key to reset it.

4. In order to discharge the DC link capacitors, insert the inverter by pressing "Inverter ON" (I) key on all UPS units.

### Remark:

Command *INVERTER ON* will be enabled only when the inverter voltage of each phase decreases below **7Vac** (about 30 seconds).

Before proceeding to step 5, check on the display panel that the *DC link voltage* (both polarities) **Vp** and **Vn** has reached the max. voltage of **5Vdc** (about 30 seconds).

The *acoustical alarm* is activated, press "MUTE" key (from Home screen) to reset it.

Home\Meter		
INVERTER		
f	:	50.0 Hz
L1	:	7 V
L2	:	7 V
L3	:	7 V
T	:	OK
SYNCHRONIZED		

Home\Meter		
BOOSTER		
f	:	50.0 Hz
L1	:	397 V
L2	:	395 V
L3	:	393 V
Vp	:	5 V
Vn	:	5 V

5. Disconnect the inverter, on all UPS units, by pressing "Inverter OFF" (O) key and hold until the LED Inverter (7) turns OFF.
6. Switch OFF the mains power, on all UPS units, at the AC input distribution panel.

## END OF PROCEDURE



### WARNING !

If the above procedure is not completely performed, it could cause serious damages to the UPS.

In case the procedure described on step "4 - Discharge DC link capacitors" cannot be completely performed, the DC capacitors could be charged with dangerous voltage for a min. 5 minutes.

The UPS cabinet contains parts electrically live.

Apart from the front door, do not open any other part of the UPS.

## 8.2.7 Restore to normal operation after "Total Off"




### NOTE !

Make sure the all units of the Parallel System to be status of the activation of "Total Off", i. e. Q1 closed, Q2 open and the "Rectifier input fuses - F1, F2, F3" and "Battery fuses - F9, F10, F11" connected.

View of the synoptic diagram, on all UPS units, after pressing the "Total Off" key.

- All Contactors are open.
- **Booster, Inverter and Static-Switch** shut-down.



### 1. Reset "Total Off" of the Parallel System.



Restore the command "Total Off", on anyone of the parallel units, by entering the screen:

COMMANDS / RESET TOTAL OFF

LED Alarm is lit.

The load is supplied by the *mains* through the *automatic bypass*.  
The *booster* starts automatically.

The *synoptic diagram*, on all UPS units, must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS**".




### 2. Insert the inverter by pressing "Inverter ON" (I) key on first UPS unit.

In case of sufficient output power, the output will transfer to *Inverter*.

LED Alarm turns Off and the LED Operation must be lit.

The *synoptic diagram*, on first UPS unit, must display the status "**LOAD SUPPLIED BY INVERTER**".




### 3. Insert the inverter by pressing "Inverter ON" (I) key on all other UPS units.

Do not start the next *inverter* until the sequence of the previous one ends.

As soon as the output power of the *inverters* is sufficient to supply the *load*, the output of the units with running *inverter* will transfer to *inverter*.

LED Alarm turns Off and the LED Operation must be lit.

The *synoptic diagram*, on all UPS units, must display the status "**LOAD SUPPLIED BY INVERTER**".



**END OF PROCEDURE**

## 8.2.8 Restore to normal operation after "EPO – Emergency Power Off"




### NOTE !

Make sure the all units of the Parallel System to be status of the activation of "EPO - Emergency Power Off", i. e. Q1 closed, Q2 open and the "Rectifier input fuses - F1, F2, F3" and "Battery fuses - F9, F10, F11" connected.

View of the *synoptic diagram*, on all UPS units, after pressing the push-button "EPO - Emergency Power Off":

- All *Contactors* are open.
- *Booster, Inverter* and *Static-Switch* shut-down.




### 1. Reset the push-button "EPO".

Press *MUTE* key to reset *Alarm* and *Acoustical alarm*.  
*LED Alarm* remains lit.

### 2. Reset the UPS by pressing "Inverter OFF" (O) key on all UPS units.

The load is supplied by the *mains* through the *automatic bypass*.  
The *booster* starts automatically.


The *synoptic diagram* must display the status "**LOAD SUPPLIED BY AUTOMATIC BYPASS**".



### 3. Insert the inverter by pressing "Inverter ON" (I) key on first UPS unit.

In case of sufficient output power, the output will transfer to *Inverter*.  
*LED Alarm* turns Off and the *LED Operation* must be lit.

The *Synoptic diagram*, on first UPS unit, must display the status "**LOAD SUPPLIED BY INVERTER**".




### 4. Insert the inverter by pressing "Inverter ON" (I) key on all other UPS units.

Do not start the next *inverter* until the sequence of the previous one ends.

As soon as the output power of the *inverters* is sufficient to supply the *load*, the output of the units with running *inverter* will transfer to *inverter*.

*LED Alarm* turns Off and the *LED Operation* must be lit.

The *Synoptic diagram*, on all UPS units, must display the status "**LOAD SUPPLIED BY INVERTER**".



**END OF PROCEDURE**

## 9 CUSTOMER INTERFACE





Fig. 9-1 Slot connectivity

LP33 Series 10 & 20 is supplied by a standard **Serial Port J27 - RS232** (see Section 9.1) and a **Relay Card** (see Section 9.2).

**List of possible connectivity configurations on LP33 Series 10 & 20**


Slot 1 – J4	Slot 2 – J3	Slot 3 – J5	Slot 1 – J4 + Slot 2 – J3
Relay Card (standard)			
Relay Card (standard)	Advanced SNMP Card (Option)		
Relay Card (standard)	Advanced SNMP Card (Option)	Advanced SNMP Card (Option)	
			Customer Interface board (Option)
		Advanced SNMP Card (Option)	Customer Interface board (Option)

## 9.1 SERIAL PORT J27 - RS232



The serial port J27 - RS232 is enabled on all the units of the Parallel System.

### Serial port J27 - RS232 connection to PC with RS232 1:1 cable DB9m - DB9f



## 9.2 RELAY CARD



### WARNING !

Connections described in this chapter shall be done only by a trained person or **SERVICE ENGINEERS**.

The **Relay Card**, allows the programming of **4 output channels** on dry contacts, which can be read on either terminal **J3** or plug **J4** (sub - D - male 9 pin).




Fig. 9.2-1 Relay Card

### Output signals on voltage-free contacts

On terminals **J3** or **J4** connector **4** of the following **28 signals** can be selected from the display (access only with password): **SETUP / SETUP / LEVEL 2: SERVICE**.

- |                                    |                          |
|------------------------------------|--------------------------|
| 0 - NO SIGNAL                      | 15 - BATTERY DISCHARGE   |
| 1 - BUZZER                         | 16 - MANUAL BYPASS ON    |
| 2 - GENERAL ALARM (NO)             | 17 - RECTIFIER ON        |
| 3 - LOAD ON MAINS                  | 18 - INVERTER ON         |
| 4 - STOP OPERATION                 | 19 - BOOST CHARGE        |
| 5 - LOAD ON INVERTER               | 20 - BATTERY EARTH FAULT |
| 6 - MAINS FAILURE                  | 21 - BATTERY FAULT       |
| 7 - DC OVERVOLTAGE                 | 22 - RELAY INPUT 1       |
| 8 - LOW BATTERY                    | 23 - RELAY INPUT 2       |
| 9 - OVERLOAD                       | 24 - RELAY OUTPUT ON     |
| 10 - OVERTEMPERATURE               | 25 - RELAY OUTPUT OFF    |
| 11 - INVERTER-BYPASS NOT SYNCHRONY | 26 - EMERGENCY OFF (EPO) |
| 12 - BYPASS LOCKED                 | 27 - ECO MODE ON         |
| 13 - BYPASS MAINS FAILURE          | 28 - GENERAL ALARM (NC)  |
| 14 - RECTIFIER MAINS FAILURE       |                          |



### NOTE !

The function "GENERATOR ON" is not available on the **Relay Card**. In case this function is needed, the optional "**Customer Interface**" card must be installed (see Section 10.2.1).

### 9.3 EPO (EMERGENCY POWER OFF)



#### WARNING !

Connections described in this chapter shall be done only by a trained person or **SERVICE ENGINEERS**.




Fig. 9.3-1 Terminals X7 - EPO

An external Emergency switch (NC - Normally Closed voltage-free contact) can be connected on terminals **X7 / 1, 2** of the "**P2 - Mainboard**".



#### NOTE !

To enable this function, remove jumper **JP8** on the "**P2 - Mainboard**", when the cables have been already connected on **X7 / 1, 2**.



*In a Parallel System a separate NC (Normally Closed) contact must be connected individually to each unit.*

When activated, this switch causes the immediate shut-down of *booster, battery-charger, inverter*; and the *contactors K4, K6 and K7*.



#### NOTE !

This procedure could imply a load shut-down.

When the **EPO** has been activated, the system must be restored as follows:


- Press the push-button **EPO** (contact on X7 / 1, 2 is closed again).
- Press the key "**O**" (*Inverter OFF* – see Section 6.2) on the control panel.
- Press the key "**I**" (*Inverter ON* – see Section 6.2) on the control panel.



*In case of a Parallel System press the key "**O**" (*Inverter OFF*) on the control panel of each unit connected on the parallel bus and having its output switch **Q1** closed.*

## 10 OPTIONS


### 10.1 OPTIONS GENERAL VIEW



#### **RPA kit**

##### *Redundant Parallel Architecture*

Allows to extend the unit to a Parallel System with 2, 3, or 4 units connected on the same bus, which ensure the highest reliability rate and increase the power availability without prior investments.



#### **Battery Extension Packs**

Extended run-time versions are equipped with additional batteries housed in the UPS itself, to increase the back-up time of the UPS when the *mains* fails.


#### **Additional battery cabinets**

Depending on model the battery extensions can be housed in additional cabinets with the same design of the UPS cabinet, delivered with the necessary protection and connection material.

For extended run-time versions and additional cabinets see enclosed *Data Sheets*.

#### **Additional battery charge**

For battery with extended backup time (max. 8.4A).




#### **Customer Interface board**

The *Customer Interface board* allows the client the exchange of information (monitoring and control) with the following interfaces:

- Serial port RS232.
- 6 programmable output channels.
- 2 programmable input channels, of which one for "GENERATOR ON".
- EPO (Emergency Power Off).

See Section 10.2.1.



#### **Advanced SNMP Card (Simple Network Management Protocol)**

The *Advanced SNMP Card* is an Interface to the *Ethernet Network*, and provides UPS information via the standard SNMP protocol.

The UPS can therefore be managed by a *Network Management System (NMS)* or by our applications (for instance *JUMP*), which uses this information to determine the state of the UPS in order to guarantee safe and orderly shut-down of the server, when needed.


#### **GE Power Diagnostics**

*GE Power Diagnostics* is an anytime, anywhere concept in UPS status monitoring and alarm notification that has been successfully implemented in numerous of installations supporting up to multi-hundred UPS.

Based on the leading *Intelligent Remote Information System IRIS* all GE UPS types as well as 3rd party UPS are supported.

Accessing the latest site information via Web and being alerted by Email, SMS or Fax, it enables the user to make timely decisions in case of changing critical conditions.

With comprehensive data collection and analysis *IRIS* is not only a remote monitoring & diagnostics (RM&D) system but, the core of the integrated service offering *GE Power Diagnostics*.



#### **GE Data Protection**

*GE Data Protection* software can communicate with the UPS over RS-232, USB or SNMP to receive status information and measurement values of the UPS.

In case of a critical condition (time on battery, remaining battery autonomy time or low battery) for the load, the software starts a controlled shut-down.

An enhanced alarm management system provides the possibility to start applications, send messages, and send e-mails for every upcoming or disappearing alarm.

### GE Data Protection

## 10.2 OPTIONS ASSEMBLY AND CONNECTION



### WARNING !

The installation and cabling of the options must be performed by QUALIFIED SERVICE PERSON.

Make sure that the UPS installation is completely powered down.

Refer to the "Safety prescriptions - Installation" described on Section 11.

### 10.2.1 Customer Interface board




Fig. 10.2.1-1 Customer Interface

C = Common  
NO = Normally Open  
NC = Normally Closed

#### J3 serial port - RS232 (sub - D - female 9 pin)

Total remote management of the system using software *GE Power Diagnostics*, *GE Data Protection* or *GE Service Software* for system protection and management of the UPS systems.

Pin 2: TX (out)

Pin 3: RX (in)

Pin 5: GND

#### J2 connector (sub - D female 25p) - Output signals on voltage-free contacts

J2 / 1, 2, 3	NO, C, NC	MAINS FAILURE	(def. Parameter RL=1)
J2 / 4, 5, 6	NO, C, NC	LOAD ON INVERTER	(def. Parameter RL=3)
J2 / 7, 8, 9	NO, C, NC	STOP OPERATION	(def. Parameter RL=5)
J2 / 14, 15, 16	NO, C, NC	LOAD ON MAINS	(def. Parameter RL=2)
J2 / 17, 18, 19	NO, C, NC	GENERAL ALARM (NO)	(def. Parameter RL=4)
J2 / 20, 21, 22	NO, C, NC	BUZZER (acoustic alarm)	(def. Parameter RL=6)



Signals on terminals X1 and on connector J2 are in parallel and therefore not separated galvanically from each other.

The programmable signals on X1 and J2 will be disabled with Q1 open, with the exception of the signals for:

16 - MANUAL BYPASS ON

25 - RELAY OUTPUT OFF

24 - RELAY OUTPUT ON

26 - EMERGENCY OFF (EPO)

#### X1 terminal block - Output signals on voltage-free contacts

X1 / 1, 2, 3	NO, C, NC	MAINS FAILURE	(def. Parameter RL=1)
X1 / 4, 5, 6	NO, C, NC	LOAD ON INVERTER	(def. Parameter RL=3)
X1 / 7, 8, 9	NO, C, NC	STOP OPERATION	(def. Parameter RL=5)
X1 / 12, 13, 14	NO, C, NC	LOAD ON MAINS	(def. Parameter RL=2)
X1 / 15, 16, 17	NO, C, NC	GENERAL ALARM (NO)	(def. Parameter RL=4)
X1 / 18, 19, 20	NO, C, NC	BUZZER (acoustic alarm)	(def. Parameter RL=6)

#### X2 terminal block - EPO connection (Emergency Power Off)

X2 / 1, 2 (or J2 / 12, 25)	NC	EPO (Emergency Power Off)
----------------------------	----	---------------------------



To enable this function, remove jumper JP3 on the "Customer Interface" and the cable on the terminal X2 / 1, 2. (See Fig. 10.2.1-1).

Verify if the cable on the terminal X7 / 1, 2 and jumper JP8 on the control board "P2 - Mainboard" are OFF (see Fig. 10.2.1-3).

#### Programmable functions on input contacts

X1/10, 21 or J2/10, 23	User Input 1 (default = Not used)
X1/11, 22 or J2/11, 24	User Input 2 (default = GENERATOR ON)

### Output signals on voltage-free contacts

On terminals **X1** or **J2** connector **6** of the following **28 signals** can be selected from the display (access only with password): **SETUP / SETUP / LEVEL 2: SERVICE**.

0 - NO SIGNAL	15 - BATTERY DISCHARGE
1 - BUZZER	16 - MANUAL BYPASS ON
2 - GENERAL ALARM (NO)	17 - RECTIFIER ON
3 - LOAD ON MAINS	18 - INVERTER ON
4 - STOP OPERATION	19 - BATTERY BOOSTCHARGE
5 - LOAD ON INVERTER	20 - BATTERY EARTH FAULT
6 - MAINS FAILURE	21 - BATTERY FAULT
7 - DC OVERVOLTAGE	22 - RELAY INPUT 1
8 - LOW BATTERY	23 - RELAY INPUT 2
9 - OVERLOAD	24 - RELAY OUTPUT ON
10 - OVERTEMPERATURE	25 - RELAY OUTPUT OFF
11 - INVERTER-MAINS NOT SYNCHRONY	26 - EPO (EMERGENCY POWER OFF)
12 - BYPASS LOCKED	27 - ECO MODE ON
13 - BYPASS MAINS FAILURE	28 - GENERAL ALARM (NC)
14 - RECTIFIER MAINS FAILURE	

### Programmable functions on input contacts (X1 - J2)

Some UPS functions can be activated by parameters (access with password only) when an external NO contact is closed on:

NO FUNCTION

INVERTER OFF

PRINT ALL

INVERTER ON

GENERATOR ON

STATUS RELAY

Voltage free contacts: Max. DC / AC: 24V / 1.25A  
IEC 60950 (SELV circuit)  
Min. signal level: 5Vdc / 5mA

## Gen Set signalling

If an emergency generator set supplies the UPS in case of utility failure and the generator is particularly unstable in frequency, it should be suitable to install the signal "GENERATOR ON" on terminals **X1 / 11, 22** (NO - Normally Open voltage-free contact) or on connector **J2 / 11, 24** (see Fig. 10.2.1-1 / X1 and J2).

Since the Parameter for of the reading of the Generator function is password protected, call the nearest *Service Centre* for it's activation.

When this contact closes, it causes the change of certain settable functions such as:

- Enabling or disabling of synchronisation and consequently the load transfer to generator.
- The battery recharge inhibition during the generator operation, or after what delay from generator start the battery will start to be recharged.

It is advised to contact your *Service Centre* for further details.



**In a Parallel System a separate NO (Normally Open) contact must be connected to each individual unit.**

## EPO (Emergency Power Off)

An external Emergency switch (NC - Normally Closed voltage-free contact) can be connected on terminals **X2 / 1, 2** or connector **J2 / 12, 25** of the "Customer Interface" (see Fig. 10.2.1-1 / X2 & J2).




Fig. 10.2.1-2 Customer Interface board




Fig. 10.2.1-3 P2 - Mainboard



### NOTE !

To enable this function, remove jumper **JP3** on the "Customer Interface" and the cable on the terminal **X2 / 1, 2** (see Fig. 10.2.1-2).

Verify if the cable on the terminal **X7 / 1, 2** and jumper **JP8** on the control board "P2 - Mainboard" are OFF (see Fig. 10.2.1-3).



*In a Parallel System a separate NC (Normally Closed) contact must be connected individually to each unit.*

When activated, this switch causes the immediate shut-down of booster, battery-charger, inverter; and the contactors K4, K6 and K7.



### NOTE !

This procedure could imply a load shut-down.

When the **EPO** has been activated, the system must be restored as follows:

- Press the push-button **EPO** (contact on X2 / 1, 2 is closed again).
- Press the key "O" (Inverter OFF – see Section 6.2) on the Control Panel.
- Press the key "I" (Inverter ON – see Section 6.2) on the Control Panel.



*In case of a Parallel System press the key "O" (Inverter OFF) on the control panel of each unit connected on the parallel bus and having its output switch Q1 closed.*

## 10.2.2 Optional battery cabinet connection



### WARNING !

All maintenance and service works must be performed by **QUALIFIED SERVICE PERSON**.

Before connecting the UPS with an optional battery cabinet, follow the safety rules concerning the battery.

Make sure that the UPS is not powered, the "Battery fuses - F9, F10, F11" at the front of the cabinet and all the battery fuses "**Fbatt1, 2, 3, 4, 5, 6**" of the battery cabinet are removed.

The battery cabinet can be located on the right or left side of the UPS with a minimum distance of 100 mm (see Fig. 10.2.2-1).



### NOTE !

Before closing the "Battery fuses - F9, F10, F11", verify for correct polarity of the battery connection.

Check for sufficient floor loading capacity (see Technical Data Sheet).

When an additional battery cabinet is connected, no batteries must be installed inside the UPS cabinet.




Fig. 10.2.2-1 UPS with optional battery cabinet




Fig. 10.2.2-2 Battery terminals up to 21Ah




Fig. 10.2.2-3 Battery terminals over 21Ah

The cable "C", standard length 5 meters, must be routed and connected as shown in the above figures.




Fig. 10.2.2-4 PCB P2 - Mainboard

### External battery fuses Type gG-gL 660/690V (14 x 21)

3 x 25A (each rack)

Connect the Battery temperature probe **J28** to the **P2 - Mainboard**.

This probe compensates the battery charging current in function of the ambient temperature of the battery

The cable with the connector **J28** must be laid in a separated conduit protected from the external electromagnetic fields.

Once the connection between the two cabinets is achieved, install the side panel of the UPS, insert the fuses "**Fbatt1, 2, 3, 4, 5, 6**" on all the racks of the battery cabinet, whereas the "**Battery fuses - F9, F10, F11**" at the front of the UPS must not be inserted until the start-up operation of the UPS.

# 11 MAINTENANCE



## WARNING !

All maintenance and service works must be performed by **QUALIFIED SERVICE PERSON**.

## 11.1 GENERAL MAINTENANCE

A UPS system, like other electrical equipment, needs periodic preventive maintenance.

A regular maintenance check of your installation guarantees higher reliability of your safe power supply.

GE Digital Energy recommends to perform the first service within **12 months** from the commissioning date or within **18 months** from delivery date.

Subsequent services to perform every **12 months**.

Preventive maintenance work on the UPS can be done only by trained *SERVICE TECHNICIANS*.

We therefore recommend you sign a Maintenance and Service contract with the local **Service Centre** organisation.

## 11.2 SERVICE REQUIRED

If this lamp lights up during normal operation, the unit has not been serviced for the last **20'000 hours** by a **GE Digital Energy** trained technician.

Some components of the UPS which need periodic maintenance, if not replaced, could cause a reliability reduction of the supply system

We highly recommend that you contact your *Service Centre* for preventive maintenance work.

## 11.3 COOLING FAN MAINTENANCE

The expected operational life of the cooling fans is approximately **40'000 hours** of continuous operation. A high ambient temperature will shorten this operational life.

## 11.4 OTHER COMPONENTS WITH LIMITED LIFETIME

We recommend the replacement of components such as *Filter Capacitors* and *Lithium Battery* for the backup of data on the control boards of the units every **50'000 hours**.

## 11.5 BATTERY MAINTENANCE

The service life of the battery is from **3 to 6 years**, depending on the operating temperature and on the number of discharge cycles.

The UPS **LP33 Series 10 & 20** offers the possibility of *SBM (Superior Battery Management)*.

The function *SBM* can be activated through a service Parameter.

The functionality of *SBM* reduces the Battery recharging time together with improved lifetime of the Battery.

As a healthy battery is essential to the performance of the UPS, an automatic or manual battery test can be performed regularly to ensure failsafe operation, in order to check if the battery can provide the expected backup time in case of mains failure.

We recommend the battery test be performed at least every **1 month**, especially if the battery is not sufficiently discharged during normal operation.

Since the parameter enabling the *battery test* protected by *user password*, please contact your **Service Centre** for more information.

Please consider that, if you did a full battery test to verify the full runtime of the battery, the charger needs at least **8 hours** to recharge the battery up to **90%** of its capacity.

To guarantee that the battery is fully charged, the UPS system should be in operation for at least **12 hours every 3 months**.

When the condition of the battery is critical, the warning signal will be activated (general alarm, buzzer and alarm message "4118 - BATTERY FAULT").

In this case the battery must be replaced as soon as possible.

Please contact your **Centre Service**.

## 11.6 UPS ROOM CONDITIONS AND TEMPERATURE

The UPS room and the *Battery Room* have to be maintained clean and free from dust.

A high temperature of the UPS room and of the *Battery Room* affect the lifetime of several components inside the equipment.

The *Battery* is very sensitive to room temperatures above **77°F (25°C)**.



### NOTE !

Ask to your local *Service Centre* to submit the form of *Preventive Maintenance Contract* suitable for your specific needs.


It is recommended to note in this section **Notes**, with date and short description all the operations performed on the UPS, as: maintenance, components replacement, abnormal situations, etc. .

Modifications reserved Page 93/94

GE\_UPS\_OPM\_LPS\_33E\_10K\_20K\_6GB\_V010.docx User manual LP33 Series 10 & 20 CE S6

## 13 ANNEX

### 13.1 TECHNICAL DATA SHEET



#### **Technical Data Sheet**

These are included in the last section and are listings of the technical data of the UPS.


### 13.2 UPS SCHEMATIC DIAGRAMS



#### **UPS Schematic Diagrams**

The *UPS Schematic Diagrams* are included in the CD-ROM, together with the *User Manual*.

### 13.3 CD-ROM



#### **CD-Rom**

The enclosed *CD-Rom* contains the complete documentation in various languages.